Part No. P0993137 03

Business Communications Manager

DECT Installation and Maintenance Guide

NORTEL NETWORKS™

Copyright © 2002 Nortel Networks

All rights reserved. December, 2002.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks NA Inc.

Trademarks

NORTEL NETWORKS is a trademark of Nortel Networks.

Microsoft, MS, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

All other trademarks and registered trademarks are the property of their respective owners.

DECT regulatory information

CE	The CE Marking on this equipment indicates compliance with the following: This device conforms to Directive 1999/5/EC on Radio Equipment and Telecommunications Terminal Equipment as adopted by the European Parliament And Of The Council.	

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Hereby, Nortel Networks declares that Enterprise Edge/ Business Communications Manager Model No. NT7B10xxxx, is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The C4010/C4020 handset is in compliance with Council Recommendation 1999/519/EC.

The DECT Base Station shall be cabled from host PBX controller card via individually screened paired cable.

The DECT standard is an integrated solution for cordless communication services based upon these ETSI specifications:

- ETS 300-175: Digital Enhanced Cordless Telephone Common Interface
- ETS 300-176: Digital Enhanced Cordless Telephone approval test specification
- ETS 300-444: Digital Enhanced Cordless Telephone General Access Profile

The DECT module provides an interface to the Business Communications Manager for cordless handsets through a radio link with a base station connected directly to the DECT module. The interface is created by linking four BRI loops and a Mercator C8 PBX through a BRI within the module circuitry.

Electromagnetic compatibility

DECT standard complies with the following safety and electromagnetic compatibility recommendations:

- ETS 300329: Radio Equipment Systems; Electromagnetic Compatibility for Digital Enhanced Cordless Telephone.
- EN 60950: Safety of Information Technology Equipment.
- EN 55022: Electromagnetic Compatibility for Information Technology Equipment.

Contents

DECT regulatory information 2
Electromagnetic compatibility 3
Preface 13
Symbols Used in this Guide 13
Text Conventions Used in This Guide 14
Acronyms 14
Related Publications 15
Chapter 1
DECT system overview and requirements 17
DECT features 18
Business Communications Manager features 18
Handset features 19
Setup process overview 20
DECT base station deployment planning 21
DECT radio base station 21
External antennas 22
Specifications for DECT radio base stations 23
Base station notes: 24
Climatic conditions 24
Power supply 25
Description of the connection 25
DECT cordless handsets 25
Site configurations 25
DECT call paths 26
DECT programming overview 26
DECT interface commands 27
Numbering plan syntax 27
Business Communications Manager requirements 28
Checking the System Region 28
Chapter 2
Installing the DECT media bay module 31
Setting the DIP switches 32
Installing the DECT module 34
Restoring the system 36
Chapter 3
Configuring the DECT module 37
Confirming the DECT module 38
Configuring the module for µ-law 39

Before you start 39
Setting up the DECT file for upload 40
Resetting the module to default values 41
Checking the Unified Manager handset DNs 42
Setting up the handsets 43
Stand-alone handset 43
Internal calls 43
External calls 44
Assigning handsets to fixed telephone DNs 45
Handset feature programming 45
About the DECT Wizards 45
DECT Configuration Wizard 46
Before you start 46
Using the Configuration Wizard 48
Setting up the module Time Synch 49

Chapter 4
Installing the DECT base station 51

Installing base station hardware 51
Special considerations 51
Installing the base station on the wall 52
Base station connections 53
Connecting the base station to the system 54
Checking the base station wiring 54
Attaching the base station to the module 55
Base station antennas 56
Attaching external antennas to the base station 57

Chapter 5
Subscribing DECT cordless handsets 59

Base station recording status 60
DECT Mobile Recording (Handset Subscription) Wizard 60
Before you start 60
Filling out the Mobile Recording (Handset Subscription) Wizard 61
Turning off mobile recording 61
Subscribing DECT cordless handsets 61
Handset buttons 61
Subscribing a handset 62
Resetting the base station 63
Checking handset status 63
Confirming base station readiness 64
Setup test 66
Handset system features 67

Message Waiting Indicator (MWI) 68
Programming the MWI lamp button 68
Twinning features 68
CallPilot programming 68
Auto-answer issues 69
Receiving a page 69
Roaming 69
Roaming on outgoing calls 70
Direct Inward Roaming 70

Chapter 6
Programming DECT module defaults 71

Opening the Maintenance Console 72
System Management 72
DECT and handset passwords 73
Language Management 74
Card Management 75
External antenna settings 75

Chapter 7
Programming numbering plans and base stations 77

Planning your DECT settings 78
Setting DECT PARI values 79
Telephony Management 80
Numbering Plans 80
Outgoing Numbering Plan 80
User Numbering Plan 82
Incoming Call Numbering Plan 83
Wireless Management 84
Cell names 84
Managing Logical Trunks 85

Chapter 8
Programming DECT handset records 87

Confirming the DECT settings 87
Identifying base stations 88
Mobile Management 90
Listing mobiles (handsets) 91
Identifying handsets 92
Removing handsets 92
Confirming the handset extension record 93

Chapter 9
Maintaining and upgrading DECT software 97

Accessing the BRU screen, Unified Manager menu 97
Accessing the BRU screen, DECT Tools menu 98
Backup and Restore DECT module data 99
Backing up DECT data 99
Restoring DECT data 101

Chapter 10
Troubleshooting and Alarm Monitoring 103

Radio base station fault on startup 103
Business Communications Manager application control 103
Setting up the Maintenance Console 105
Viewing and changing Service Status 105
Viewing alarms 106
Base station/handset troubleshooting 107
Changing the TCPPort 107
Monitoring the DECT module LEDs 108
Determining module companding law setting 108

Appendix A
Quick reference to DECT module programming 111

Appendix B
Cordless handset verification 115

Determining handset subscription 115
Unsubscribing the handset 116
Testing the handset 117
Glossary 119
Index 123

Figures

Figure 1 Integrated DECT service 17
Figure 2 Setup process for the DECT system 20
Figure 4 Antenna configurations 22
Figure 3 Base station switches 22
Figure 5 Inside the DECT radio base station 23
Figure 6 Process for installing the DECT module 31
Figure 7 Locating the DECT media bay module dip switches 32
Figure 8 Release tabs for the module bays 35
Figure 9 Front bezels replaced on units 35
Figure 10 Locating the LEDs on the DECT module face 36
Figure 11 Process for identifying and configuring the DECT module 37
Figure 12 Maintenance/Maintenance Tools/DECT Tools 40
Figure 13 Firmware upload 41
Figure 14 Restore default firmware configuration 41
Figure 15 Time synchronisation page 49
Figure 16 Base station with cover pulled away 52
Figure 17 RJ45 connectors on the media bay module 55
Figure 18 Status LED on outside of base station 56
Figure 19 Removing the internal antenna plate 57
Figure 20 Process for subscribing the cordless handsets 59
Figure 21 Define Radio Base Station XX DECT screen 64
Figure 22 Wireless Management Menu menu 64
Figure 23 Wireless Resources Menu menu 65
Figure 24 Base Station Selection menu 65
Figure 25 Define Radio Base Station XX DECT screen 66
Figure 26 DECT interface, system management 71
Figure 27 Main DECT maintenance menu 72
Figure 28 System Management menu 73
Figure 29 Password Management menu 73
Figure 30 Parameter Management menu 74
Figure 31 Wireless Resources menu 75
Figure 32 Base station screen 76
Figure 33 DECT interface, trunk and cell management 77
Figure 34 Wireless Management menu 79
Figure 35 Wireless Topology menu 79
Figure 36 DECT parameters screen 79
Figure 37 Telephony Management menu 80
Figure 38 Numbering Plan menu 80
Figure 39 User Numbering Plan menu 81
Figure 40 DECT directory numbers 81

Figure 41 Local Dialing List 82
Figure 42 Incoming Call Numbering Plan menu 83
Figure 43 Incoming plan: Internal numb. 83
Figure 44 Wireless Management menu 84
Figure 45 Wireless Topology menu 84
Figure 46 Wireless Resources menu 85
Figure 47 Telephony Management menu 87
Figure 48 Wireless Management menu 87
Figure 49 Wireless Resources menu 88
Figure 50 Wireless Resources menu 88
Figure 51 Base station screen 89
Figure 52 Wireless Mobiles menu 91
Figure 53 Display Mobiles screen 91
Figure 54 Create mobile record 92
Figure 55 Extension Data menu 93
Figure 56 Extension Characteristics menu 93
Figure 57 Handset record, page 1 94
Figure 58 Handset record, page 2 94
Figure 59 Handset record, page 3 95
Figure 60 Maintenance/Maintenance Tools/DECT Tools 98
Figure 61 Backup and Restore Utility screen 99
Figure 62 Scheduling a backup, one time 100
Figure 63 Backup and Restore Utility screen 101
Figure 64 Backup and Restore Utility, restore screen 101
Figure 65 Services list 103
Figure 66 Services list for DECT Maintenance Console 104
Figure 67 Alarm Banner 106
Figure 68 Alarm Details screen 106
Figure 69 Test mode display screen 117

Tables

Table 1 Hardware components of the DECT system 18
Table 2 Parts of the DECT radio base station configurations 21
Table 3 Generated losses with extension cord added 23
Table 4 DECT interface commands 27
Table 5 Numbering plan syntax 27
Table 6 DECT switch settings 33
Table 7 Module settngs 34
Table 8 Possible causes of interference 53
Table 9 Cable lengths and resistances 54
Table 10 Base station LED conditions 56
Table 11 External antennas 57
Table 12 Buttons used during handset subscribing 61
Table 13 Troubleshooting the preliminary operations 66
Table 14 Identifying cell, trunk and base station assignments 78
Table 15 Identify the outgoing and incoming numbering codes for your system . . 78
Table 16 DECT defaults: 82
Table 17 Status options for DECT services 104
Table 18 Possible status settings 105
Table 19 Base station/handset troubleshooting 107
Table 20 LED states 108
Table 21 Test mode icon definitions 118

Preface

This guide describes how to install and initialize a DECT system. Information in these chapters explains:

- how to set up and operate the DECT media bay module
- how to set up and operate the radio base stations
- how to subscribe the cordless handsets to the system

To use this guide, you must:

- be a Nortel Networks installer with Business Communications Manager certification
- know basic Nortel Networks terminology
- have a working Business Communications Manager system that is compatible with the DECT application

Symbols Used in this Guide

This guide uses symbols to draw your attention to important information. The following symbols appear in this guide:

Note: Note Symbol

A note alerts you to important information.

Tip: Tip Symbol

A tip adds general information pertinent to the current process.

Alerts you to ground yourself with an antistatic grounding strap before performing the maintenance procedure.

Alerts you to remove the Business Communications Manager server and Business Communications Manager Expansion Cabinet power cords from the a.c. outlet before performing the maintenance procedure.

Caution: Caution Symbol

Alerts you to conditions where you can damage the equipment.

Danger: Electrical Shock Hazard Symbol

Alerts you to conditions where you can get an electrical shock.

Warning: Warning Symbol

Alerts you to actions that can make the system non-operational.

Text Conventions Used in This Guide

This guide uses the following text conventions:

`bold Courier text`	Indicates command names and options and text that you need to enter in a command-line interface. Example: Use the **`dinfo`** command. Example: Enter **`show ip`** {**`alerts`**|**`routes`**}.
italic text	Indicates file and directory names, new terms, book titles, Web addresses, and variables in command syntax descriptions.
bold text	Indicates command names, screen titles, options and text that you need to enter in a graphical user interface (GUI).
angle brackets (< >)	Indicates a keyboard key press or simultaneous key presses i.e. <ENTER> or <CTRL j>

Acronyms

This guide uses the following acronyms:

AC	Authentication code
ADPCM	Adaptive differential pulse code modulation
ARI	Access right identity
BRI	Basic rate interface (module)
DECT	Digital enhanced cordless telecommunications or Digital European cordless telephone
DID	Direct inward dial
DSAA	DECT standard authentication algorithm
DTM	Digital trunk module
EIC	Equipment installation code
FPN + FPS	Fixed part number and fixed part sub-number

ISDN	Integrated services digital network
LAL	Location area level
LED	Light-emitting diode
MWI	Message waiting indicator
PARI	Primary access right identity
PARK	Portable access right key
PARK{y}	PARK with PLI y
PBX	Private branch exchange
PLI	Park length indicator
PSTN	Public switched telephone network
RFPI	Radio fixed park identity
RSSI	Radio signal strength indicator
SARI	Secondary ARI
TCM	Time compressor multiplexor
WAN	Wide area network

Related Publications

For more information about the Business Communications Manager server and related media bay modules, extension equipment, and the applications and software on the system, refer to the following publications, which are located on the CD that came with your Business Communications Manager 3.0 system or upgrade:

- *Installation and Maintenance Guide* describes the process of installing and maintaining the Business Communications Manager equipment. The book includes descriptions of the available modules.
- *Programming Operations Guide* describes how to program the Business Communications Manager equipment.
- If your Business Communications Manager has an internal voice mail system, refer to the documents specific to your system for setting up voice mail for your DECT handsets. If your system is part of a network connected to a Meridian system voice mail, refer to the Meridian voice mail documentation.

Chapter 1
DECT system overview and requirements

The DECT system provides the Business Communications Manager with the ability to connect cordless telephones to the system for use within the local area.

There are specific Business Communications Manager profiles that can use this equipment. Refer to "Checking the System Region" on page 28. Other profiles are for countries that have other technology for this purpose.

Warning: Do not attempt to change a region setting on an active system. This can cause the system to reset and lose data.

This chapter describes the DECT system components and provides an overview of the installation process. It also includes instructions for ensuring that your Business Communications Manager is set to the correct profile to accept and work with the DECT equipment.

Deployment and site preparation details are provided in a separate document. This chapter provides a brief overview of this task, as well as the specifications for the components.

Finally, the chapter provides an overview of system operations. This includes the load required on the Business Communications Manager and general commands you require to work on the DECT interface.

Figure 1 shows a graphic representation of the components of the system.
Table 1 on page 18 describes the three main hardware components of the DECT system.

Figure 1 Integrated DECT service



Table 1 Hardware components of the DECT system

Component	Function
DECT media bay module	The module connects up to eight radio base stations. Use the Business Communications Manager Unified Manager application to initialize and program the module. Within the module, four BRI ISDN loops allow up to eight simultaneous conversations. NOTE: Each Business Communications Manager system can support one DECT module.
M6241 Radio base station	Each base station provides radio coverage for a prescribed area. A group of base stations make up a cell. Each base station can support up to four simultaneous calls. The radio base stations also offer antenna diversity. Use the site survey to determine the number of base stations required to cover the area. Refer to "DECT base station deployment planning" on page 21.
DECT cordless handset C4010 and C4020	Each handset provides the user with telephony features remote from the land set. This book contains only the registration operations for the set. Refer to the user manuals that came with your handset for operational details. Up to 32 handsets can be assigned to each DECT system.

DECT features

The following list describes some of the special features of the DECT system.

- The DECT module contains four BRI ISDN-S loops. The Business Communications Manager assigns four loop records in the Unified Manager when the module is installed, based on the DIP switch settings for the module.
- The cordless handsets are identified with DNs in the Unified Manager. They can be assigned answer DNs to link them with stationary sets.
- The numbering plan and call routing defined in the Business Communications Manager must agree with the entries in the DECT interface.

Also refer to "Handset system features" on page 67.

Business Communications Manager features

The DECT system supports the following Business Communication Manager call processing features:

- autodial keys (handset-based)
- answer keys
- busy lamp indication

Note: A desk set with a DECT answer DN will indicate the status of the DECT handset, but a DECT handset cannot display the status of a desk set because it has no display keys.

- call capture
  - — incoming calls can be redirected to the prime set or a voice mail box
  - — a system telephone calling a DECT handset will continue to ring even after the handset ring timer runs out. It is recommended that all DECT handsets be set for Call Forward No Answer to deal with this issue.
- call display when busy: handsets will only get a busy signal
- call forward (all calls, busy, no answer)
- call identification: available, depending on system programming
- class of service/dialing restrictions
- conference calling
- delayed Ring Transfer to Prime if the DECT handset is not answered
- dial external/outgoing line identification
- intercom lines
- external line access using line pool codes or destination codes
- hold
- hunt group functionality
- multiple line appearances
- on hook dialing
- private lines (incoming)
- remote access
- ringing, restriction, and routing services
- set name
- target line (direct call from external line)
- transfer
- voice mail support to retrieve pending messages

Features not included on this list are not supported on the handset by the Business Communications Manager system.

Handset features

These features are provided by the DECT handset, and are not necessarily exclusive to Business Communications Manager operation.

- dial pad feedback
- feature access key
- headset
- hearing aid compatibility
- language choice
- last number redial
- on hook dialing from numbers stored in handset memory
- ringing line preference
- set speed dial

Refer to the DECT documentation that came with the handset for details.

Setup process overview

Figure 2 provides an overview of the actions required to successfully set up the DECT integrated system:

Figure 2 Setup process for the DECT system


Plan the deployment
Have a site plan and deployment strategy worked out. Refer to the *M6261DECT Deployment Tool Guide* on the Business Communications Manager 3.0 CD.
Data report
Site survey
Radio base stations locations
Plan cells
Check BCM system settings
Ensure that your Business Communications Manager has the correct Region setting to allow DECT deployment. Refer to "Checking the System Region" on page 28.
Install media bay module
Refer to Chapter 2, "Installing the DECT media bay module," on page 31.
This procedure assumes the Business Communications Manager is installed and commissioned.
Install the radio base stations
Refer to Chapter 4, "Installing the DECT base station," on page 51.
Check the site map for obstacles and possible sources of interference to the radio signal or data link.
Connect base stations to module
The first radio base station must be within 800 m of the DECT media bay module. Attach the components using 0.6 mm cable.
Program the DECT module
Refer to "Configuring the DECT module" on page 37 for instructions about setting up the module through the Unified Manager, and running the DECT wizards. Chapters 6 to 8 provide instructions for manually configuring the DECT module settings.
Subscribe cordless handsets
Refer to Chapter 5, "Subscribing DECT cordless handsets," on page 59.
When the system and module DNs have been assigned, subscribe each handset. Test the handsets with each base station.
Maintenance tools
For some functions, DECT works separately from other applications on the Unified Manager. Use the tools found under the **Maintenance** button on the first page of the Unified Manager to perform these functions: Time synch, Firmware upload, Backup/Restore/Scheduling, Restore default, and viewing the current Companding law setting.

DECT base station deployment planning

The DECT base stations must be deployed to provide full site coverage with the maximum traffic capacity, using the minimum number of base stations.

There are two tasks involved in arranging this:

- Surveying the site: the site survey involves gathering information to determine customer requirements and the number of cells needed to support the traffic.
- Planning deployment: deployment plans establish the best locations for the radio base stations.

Site surveying and deployment planning are complex tasks, undertaken only by trained personnel. Refer to the *M6261DECT Deployment Tool* and site planning guide for detailed Site planning and deployment.

DECT radio base station

The Business Communications Manager can support one DECT media bay module.

A cable attached to an RJ45 connector in the face of the DECT module connects to the base station RJ45 connector. This supplies the data and power.

The base station comes with two internal antennas to provide signal diversity. Some types of external antennas can be substituted, depending on site requirements.

Table 2 describes the function of the parts of the base station.

Table 2 Parts of the DECT radio base station configurations

Part	Description of function
Base stations	The area covered by the base station depends on the radio range. Base stations manage the links with the cordless handsets within that range.
Cables	The cable includes two telephone pairs. One transmits the signal. One receives the signal.
Connectors	The base station uses a female RJ45 to connect to the cable.
Switches	There are two configuration switches: the CA1 and the S202. • The CA1 has two switches, labelled 1/2 and 3/4. Set 1/2 to On to enable the adaptation resistor for the synchronization pair. Set 3/4 to On to enable base station Reset. Set 3/4 to Off to run Reset by S0 interface level 1. • The S202 has two switches, labelled 1/2 and 3/4. Set 1/2 and 3/4 to On to enable the 100 ohm adaptation resistors for the S0 pairs. Refer to Figure 3 on page 22.

Table 2 Parts of the DECT radio base station configurations (continued)

Part	Description of function
	Figure 3 Base station switches 

External antennas

Three kinds of external antennas can be added:

- The MA431X23 is omnidirectional with an extension cord.
- The MA431X24 is omnidirectional with an extension cord.
- The MA821X12 is bidirectional with a 50-cm cable.

The HT6176A is an adapter for outdoor antennas.

Warning: Do not add any longer cables to the MA821X12, or the gain and receptivity will suffer. Place this antenna as close to the base station as possible.

The MA431X23 and X24 antennas can be installed further from the base station. Ensure that the coaxial cables linking the antennas with the base stations provide low attenuation. Figure 4 illustrates two configurations:

Figure 4 Antenna configurations



- The internal antenna incorporates an MMS connector (1), one coaxial cable KX21 (2) and the radiating element (3). The antenna gain is 2 dBi.

- The external antenna is connected via a cord (4-5-6) which incorporates an MMS male connector (4), coaxial cable KX21 (5) and a TNC female connector (6). The manufacturer specifies losses of less than the guaranteed dB value. Losses are actually of the order of 0.7 dB at 2 GHz.

  The extension cord conveying the signal to the antenna incorporates a TNC male connector (7), low loss coaxial RG58cu cable (8) and N male connector (9). The antenna (11) is secured to the extension cord using N female connector (10).

The losses generated by this extension cord are summarized in Table 3:

Table 3 Generated losses with extension cord added

Element	Losses at Frequency	Estimated losses
RG58cu	0.65dB/m at 2GHz	
TNC	0.2 dB at 9GHz	0.1 dB
N	0.15 dB at 10GHz	0.1 dB

- The maximum length of the extension cord is 2.8 meters.
- The MA432X23 external antenna with an extension cord performs approximately in the same way as an internal antenna, except for the polarization diversity.
- The MA432X24 provides a 2 dB gain compared to the internal antenna.

Specifications for DECT radio base stations

This section describes the radio base station specifications.

Figure 5 shows the base station with the top cover removed.

Figure 5 Inside the DECT radio base station



The following specifications apply to DECT radio base stations:

- frequency band: 1880 -1900 MHz
- number of radio channels: 8
- transmission power: 250 mw (peak)/10 mw (average)
- instantaneous throughput of the channel: 1152 Kb/s
- signaling channel throughput (D channel between the module and the base station): 16 Kb/s.
- antenna type: omni-directional [one-way] or directional integrated or external antennas
- coverage range: from 10 to 30 metres (office environment), up to 300 metres (open air)
- radio base station operating temperature: +5 to +45 degrees Celsius
- number of simultaneous calls per radio base station: two or four
- base station synchronization: yes

Base station notes:

Here are some general-information notes about the base station:

- Do not install more than two overlapping radio base stations per cell.
- Do not apply any paint or other wall covering to the plastic shell without written approval from Nortel Networks.
- Use the Unified Manager to perform resets of the base station.
- Signal processing functions for the four-channel radio base station are ported to the media bay module. In this case, the interface transports four 32 Kb/s ADPCM coded communications as well as 16 Kb/s signaling channel.

Climatic conditions

The DECT base station can tolerate the following conditions:

Operational:

- Temperature: 5 to 45 degrees C.
  - 20 to +60 with a special cabinet
- Relative humidity: 10 to 80%, not condensing.

Storage:

- Temperature range: - 10 to 60 degrees C.
- Relative humidity range: 10 to 90%, not condensing.

Power supply

The ISDN interface in the DECT media bay module enables the base stations to be powered through the cable connection between the DECT and the base station. The remote power supply is limited to 100 mA on the DECT interface, which corresponds to an available power of 4 W at 48V.

The radio base station can also be powered using a local a.c./d.c. mains power supply unit, PN 840 B. Use a local supply unit for no more than two radio base stations in any given cell.

Description of the connection

DECT base stations connect to DECT media bay modules using a cable containing two twisted pairs. This cable connects to RJ45 connectors on the components. The connection at the DECT position corresponds to an equipment number on the two cards on the DECT module that control the base station interaction. If you assign specific base stations to equipment numbers, you must ensure that base station is connected to the appropriate RJ45 jack on the DECT module.

DECT cordless handsets

Check for small metal objects in the DECT Handset earpiece/mouthpiece before using the handset.

Do not store or locate flammable liquids, gases, or explosive materials in the same compartment or vicinity as the cordless handset, its parts or accessories.

This section describes the features provided by the C4010 and C4020 cordless handsets. These handsets were developed to work with DECT systems.

Other cordless handsets can be used with the DECT system. The system features available to other handsets depends on how the handset is configured, and how compatible it is with the signals transmitted from the DECT module. As well, some features such as call display also require the proper line configurations at both the local and telco end of the line.

Site configurations

Nortel Networks provides one PARI number on the DECT module that all the base stations share. Access is authorized by matching the PARI number and the PARK number registered in the Other multi-site configurations.

DECT call paths

The DECT module provides a telephony path separate from the Business Communication Manager system. This means there are three possible paths for a call to take.

- A DECT handset-to-handset call is routed from the calling handset, through the DECT module C8 interface, into the receiving handset.
- A DECT handset-to-Business Communications Manager set call is routed from the calling handset, into the C8 interface, and into the Business Communications Manager. The Business Communications Manager then routes the call through the appropriate station module to the receiving set.
- A DECT handset-to-external call is routed from the calling handset, into the C8 interface, and into the Business Communications Manager. The Business Communications Manager then routes the call through the appropriate trunk module out to the public network. This is the same route a call from a DECT handset to a set on a private network would use. The difference is that the user enters a different destination code.
- If a DECT handset transfers a call, the DECT C8 processes the transfer and creates a new call destination. The call remains routed through the C8 interface, even though the DECT handset is no longer involved in the call.

DECT programming overview

Here are some important points about using DECT on your Business Communications Manager.

- The Business Communications Manager must be configured with a region setting that provides DECT support.

Note: Valid DECT region settings:

Australia, Denmark, France, Germany, Global, Holland, Italy, Norway, Spain, Sweden, Switzerland, Taiwan, United Kingdom

- The system default password is set to `insta`. You can delete or change this password to suit your needs.
- Default language is English.
- Disable the base stations before a firmware upgrade. Put the base stations back in service in sequence.
- To subscribe handsets, a base station must be set to accept handset recording.
- The handset DN must also be set into recording mode before the handset can be subscribed.
- The system uses data links.

- Within the DECT interface, numbers enclosed in ( ) indicate length of parameters.

Note: Refer to the *Business Communications Manager Programming Operations Guide* to configure telephony parameters for each handset DN.

DECT interface commands

Table 4 shows the main commands that are needed to navigate the DECT interface.

Table 4 DECT interface commands

Command	Explanation
Ctrl U	Goes to main menu.
Ctrl J	Moves up one level of menus.
space bar	Toggles between items within screens.
Esc (alpha commands)	ESC M = more A list displays at the bottom of each screen.
Del	Deletes item backwards.
Note: Data changes take effect immediately! There is no UNDO option.	

Numbering plan syntax

Table 5 explains how the syntax for the numbering plan works:

Table 5 Numbering plan syntax

Number Plan width	Entry	Means
(2)	1-2	10 to 29
(3)	12-3	120 to 139
(5)	1623-4	16230 to 16249
(5)	1-2	10000 to 29999

Business Communications Manager requirements

The DECT system only works with a Business Communications Manager system that has been set to a compatible region. Region settings determine basic system compatibilities with local telephony protocols. Confirm the region on your Business Communications Manager before you attempt to install the system. Regions are discussed in the *Business Communications Manager Programming Operations Guide*.

This book describes the handset directory number (DN) system based on the default setup, where the Start DN is 221 and the DN length is three digits. If your system has a different DN structure, use the tables provided to translate the DNs listed to match those of your system.

Examples of DN structures:

If your Start DN is 221 but you require a five-digit DN, the system automatically creates a Start DN of 22221 when you specify a five-digit DN at startup.

If your Start DN needs to start with a specific number, change the Start DN after you specify the DN length at startup. For instance, if your Business Communications Manager is part of a CDP (Coordinated Dialing Plan) network with five-digit DNs, your system must have a unique first DN digit, so you would specify the exact Start DN, in this case, something like 31111.

Checking the System Region

If you experience problems configuring the DECT module on your system, check the region for which the system is set.

Note: DECT systems can be installed in countries that can run the following region profiles: UK, Australia, Sweden, Denmark, Holland, Norway, Italy, Germany, Spain, Switzerland, France, Global, Taiwan.

Refer to the *Business Communications Manager Programming Operations Guide* appendices for the table that lists all the regions.

Caution: You must select a region that reflects the geographical location of the Business Communications Manager.
If you choose the incorrect region, the Business Communications Manager system does not communicate correctly with the Public Switched Telephone Network.

This procedure describes how to ensure that the Business Communications Manager is set to the correct region for the DECT module.

1. Open the Unified Manager for your Business Communications Manager system.
2. On the navigation tree, click **Diagnostics/MSC.**
3. On the top menu, click on **Configuration**.
4. Click **System startup.**
5. Ensure that the Region box displays the correct region.

Warning: If you reset the region profile on the Business Communications Manager, the system is reset to default parameters. Therefore, ensure that you have a current backup before you attempt to do this procedure.

   a. To change the region, select a region from the list.

Note: When you select a new region, the Template box is disabled. You must restart the system before the templates for the selected region are available.

   b. Click **OK** to apply these changes.

Note: The system displays a warning that the system will restart and that the default programming values will be restored.

   c. Click **Cold Start** to restart the Unified Manager.

6. Continue with the DECT deployment.

Chapter 2
Installing the DECT media bay module

This section describes how to install the DECT media bay module in the Business Communications Manager. Figure 6 shows an overview of the process.

Figure 6 Process for installing the DECT module


Site planning is complete
Base stations are installed
Note the PARI number on the side of the module
Set the DIP switches on the back of the DECT module
Prepare system for shutdown
Shut down the system
Remove the front bezel
Remove the media bay cover
Install the DECT module
Restore system to operation
Go to Chapter 3, "Configuring the DECT module," on page 37 to perform the module identification and initialization.

Setting the DIP switches

This procedure describes how to set the DIP switches for the DECT media bay module.

Ensure that you wear equipment to properly ground yourself while handling any of the electronic parts to this system.

1. Take the media bay module from its box.
2. Inspect the module for damage.
3. Make a note of the PARI number, which is located on a label on the module.
4. Determine which DS30 channel (bus) number to use for the module.

Note: Remember that the channel you choose cannot conflict with a location already assigned to an existing media bay module.

Use Bus 6 or 7 if they are available.

5. Set the DIP switches, located on the back of the DECT module to the DS30 channel number. Set the offset to 0 (on).

   Figure 7 shows the location of the DIP switches on the DECT module.

Figure 7 Locating the DECT media bay module dip switches



- Table 6 shows the switch settings for each DS30 channel number. The offset number is always 0.

Table 6 DECT switch settings

Select DS30 channel	Select offset	Set the switches						Use these DNs on new 2.5 or greater systems	Use these DNs on updated 2.0 system	**Customized DN range
		Offset			DS30 channel					
		1	2	3	4	5	6			
2	0	on	on	on	on	on	on	597-624*	501-532*	
3	0	on	on	on	on	on		597-624*	501-532*	
							off			
4	0	on	on	on	on		on	597-624*	501-532*	
						off				
5	0	on	on	on	on			597-624*	501-532*	
						off	off			
6	0	on	on	on		on	on	597-624*	501-532*	
					off					
***7	0	on	on	on		on		597-624*	501-532*	
					off		off			

*If you need more DNs, use DNs in the portable DNs, starting at 565. Ensure no other devices are assigned to these DNs before you use them.

**Note: The extensions listed are based on a three-digit DN with a Start DN of 221. If your system has longer DNs or a different Start DN, enter the range in the blank column.

***If your system has a 3/5 DS30 channel split, channel 7 is not available to media bay modules. Refer to the *Business Communications Manager Programming Operations Guide* for further information on this feature.

Note: If you replace a module, set the DIP switches for the new module to exactly the same settings as the removed module.

TIP: Numbering conventions:

This document assumes three-digit DNs, starting with a Start DN of 221. If your system has a different numbering plan, adjust the numbering accordingly. If you follow a different numbering plan, ensure that you update all the DN settings described in Chapter 8, “Programming DECT handset records,” on page 87.

Use Table 7 to note the settings you chose.

Table 7 Module settngs

Module PARI number:
DS30 channel:
DIP switch settings:
Notes:

Installing the DECT module

After you have set the DIP switches, you can install the module. You need to shut down the system to install the module, therefore, choose a period when the Business Communications Manager is not busy.

Remember to warn users that the system will be down for a short period.

1 Ensure the Business Communications Manager base unit is properly shut down.

a From the Unified Manager application, click **System**, then go to the **Logoff** menu and click **Shutdown**.

For detailed shutdown information, refer to the *Business Communications Manager 2.5 Programming and Operations Guide*.

b Disconnect all the cables from the front of the Business Communications Manager base unit and expansion unit, if there is one.

c Disconnect the base unit and expansion unit power cords from the a.c. outlet.

Danger: Failure to follow these steps can result in damage to the system or the module.

d Remove the front bezel from the front of the base unit or expansion unit where you plan to install the DECT module.

2 Remove the blank cover from the module bay.

To remove the bay cover, pull the tab beside the module bay. This pushes the cover forward. Figure 8 shows the module release tabs on the base unit and expansion unit.

Figure 8 Release tabs for the module bays


Business Communications Manager base unit
Media bay coverplate and module release tabs
Business Communications Manager expansion unit

3 Insert the module into the open bay and push until the module clicks into the backplate.

Note: The module protrudes slightly. After the front bezel is replaced, the face of the module sits flush with the front of the unit.

4 Replace the front bezel on the base unit or the expansion unit.

Figure 9 shows the base unit and expansion unit with the front bezels replaced.

Figure 9 Front bezels replaced on units


Business Communications Manager base unit
Bezels replaced on units
Business Communications Manager expansion unit

Restoring the system

After the module is installed, restore the Business Communications Manager operations. Then connect the base station cables to the module.

1. Inspect the system to ensure all components are in place.
2. Reconnect the a.c. power cords for the Business Communications Manager base unit and the expansion unit, if there is one.
3. Reconnect all the connections to the front of the units.

Warning: Failure to follow these steps can damage the system or the module.

4. Monitor the LEDs on the front of the DECT module to ensure the system reboots properly. Refer to Figure 10. This process takes a few minutes.
   - Power (working status)
   - Status (hardware status)
   - Run (CPU of the DECT C8 interface) (blinks when stable)
   - 48 V for the base station jacks

Figure 10 Locating the LEDs on the DECT module face



5. When the power and status LEDs on the module are solid green, you are ready to continue with the module configuration. Refer to Chapter 3, “Configuring the DECT module,” on page 37,

   If the lights are off or are blinking, refer to “Monitoring the DECT module LEDs” on page 108 for troubleshooting information.

Chapter 3
Configuring the DECT module

There are some preliminary steps that you must do within the Business Communications Manager Unified Manager application before you run the wizard that configures the DECT module. This chapter describes how to ensure that the Business Communications Manager system sees the DECT module. It also describes how to find and manage the DNs designated for DECT handsets.

When the Unified Manager settings have been done, you can run the DECT Configuration wizard. This wizard configures the DECT module. It also turns on one of the base station ports to allow handset subscription.

Handset subscription (mobile recording) can also be turned on and off using the DECT Mobile Recording (handset subscription) wizard, which is also described in this chapter.

Figure 11 describes the steps you need to take to identify and configure the DECT module.

Figure 11 Process for identifying and configuring the DECT module


Identify the DECT module
Ensure the Business Communications Manager recognizes the DECT module. Change firmware if the module requires µ-law ISDN protocol. Refer to "Configuring the module for µ-law" on page 39.
Choose handset DNs
These DNs must match the DNs you enter on the DECT interface. Use the default DNs, unless your system requires a different numbering scheme. Refer to "Setting up the handsets" on page 43.
Run the DECT Config. wizard
The DECT Configuration wizard sets up the DECT module, using the default DNs you specified. Refer to "DECT Configuration Wizard" on page 46.
Set module time synch
After you run the Wizard, ensure that the module is time synched with the Business Communications Manager. Refer to "Setting up the module Time Synch" on page 49.
Connect base stations to module
After the configuration wizard is complete, connect the base stations to the module and subscribe the handsets. Refer to "Connecting the base station to the system" on page 54, and Chapter 5, "Subscribing DECT cordless handsets," on page 59.

Confirming the DECT module

After the DECT module has been installed and the system has rebooted, you must identify the module to the Business Communications Manager system.

Use this procedure to ensure the system recognizes the module type.

1. On the navigation tree, click the key beside **Resources**.
2. Click on **Media Bay Modules**.
3. Click on the Bus number for the DECT module.
4. Ensure that **Programmed Bus Type** is set to Trunk Module.
5. Click the key beside **Modules on Bus**.
6. Click on **Module 1**.
7. Ensure that **Module Type** is set to DECT.
8. If you made changes to any of the module settings, do the following, otherwise continue with step 9:
   a. Click on the DECT module Bus.
   b. On the top menu, under **Configuration**, choose **Disable**.
   c. On the message box, click OK.
   d. On the top menu, under **Configuration**, choose **Enable**.

   When the module is enabled, the **State** field reads: equipped.
9. At the bottom of the Resources list, click on the **DECT** heading.
10. Confirm the module name, or select the correct module.

Note: If the module does not immediately appear on the list, wait a few minutes and try again.

This module type only appears when a DECT module is present on the system. If the DIP switches are set incorrectly, the setting will appear, but the module will show as *unequipped*.

Note: Companding law requirements.

The DECT module defaults to a-law. If your system requires the µ-law ISDN protocol, refer to "Configuring the module for µ-law" on page 39 for instructions about resetting the module.

Configuring the module for µ-law

The Business Communications Manager has the software for both µ-law and a-law ISDN protocols. The system defaults to a-law, as does the DECT module. To change this setting on the DECT module in countries where µ-law is required, you need to upload a new set of firmware. Follow the directions in this section to set up the module and upload this firmware.

Caution: This procedure resets the DECT module settings to the default settings, so it must be done before you run the DECT wizard.

If your system uses the a-law protocol, skip to "Checking the Unified Manager handset DNs" on page 42.

Before you start

Ensure that the following has been done before you attempt to upload new firmware to the DECT module.

1. Ensure that the Business Communications Manager system has been initialized with the correct µ-law Region profile. Refer to "Checking the System Region" on page 28.
2. If you are unsure of what your DECT module is set to, you can check the setting through the DECT module. Refer to "Determining module companding law setting" on page 108.
3. To view the companding law for the firmware that is ready to be loaded, you can check under DECT Tools. Refer to "Setting up the DECT file for upload" on page 40 for a detailed process for finding the DECT Tools pages under the **Maintenance** button on the first page of the Unified Manager.
4. On the DECT Tools page, click the **Companding Laws** link.

   The resulting page shows the current setting for the DECT firmware load that will be loaded onto the module.

Companding Schemes are shown below. ALaw is in use by default. If you would like to switch companding schemes then please click on the radio button below (A window will open that will show the progress of this process and you will be prompted upon completion). After the switch is done you must perform a *firmware upload*. **No settings will change until a firmware upload has taken place.**



Setting up the DECT file for upload

The first step is to set up the file that needs to be uploaded by the module.

1 On the Unified Manager first page, click on the **Maintenance button**.

2 On the left menu of the maintenance site, click on **Maintenance tools**.

3 On the right frame of the Maintenance Tools page, click on the link under the **DECT Tools** heading.
The DECT tools page appears.

Figure 12 Maintenance/Maintenance Tools/DECT Tools

Welcome to the DECT Tools page. Here you will find everything you need to maintain your DECT MBM. Below is a table that lists the tools available for use and the description of each.

DECT Tool	Description/Use of Tool
Time Synchronisation	DECT runs on a seperate processor than the BCM, therefore it is important that you synchronise the time of the DECT processor with the BCM Processor. You can schedule this synchronisation to run automatically or you can do it on yourself whenever you want. It is recommended that you do set a regular schedule of once a day.
Firmware Upload	Uploads the latest firmware to your DECT MBM. This process takes about 60 to 70 minutes to execute and *your DECT telephony will be unavailable* while this process executes, but your other BCM telephony will not be effected.
Backup	Allows you to backup your DECT MBM programming settings via the Backup and Restore Utility (BRU). In the BRU select DECT OAM, and then backup.
Restore	Allows you to restore your DECT MBM programming settings via the Backup and Restore Utility (BRU) . In the BRU select DECT OAM, and then restore.
Restore Default Configuration	Restores the Default Configuration of the DECT MBM programming settings.
Companding Schemes (ALaw/muLaw)	Changes the Companding (Compress/Expand) Scheme from ALaw to muLaw (or vice versa). ALaw is in use by default. After this process has completed you will then *need to run a firmware upload* before your new settings will take affect.

4 Click on the **Firmware Upload** link.

The firmware upload page appears.

Figure 13 Firmware upload

Your Location: BCM / Product Maintenance & Support / Maintenance Tools / DECT Tools / Firmware Upload
DECT Firmware Upload
Please enter your DECT Installer Password:
Execute DECT Firmware Upload

5 Beside **Please enter your DECT installer Password**, type: `insta*`

Note: *The Password listed here is the default. Your system settings may have been changed.

6 Click the **Execute DECT Firmware Upload** button.

The upload screen appears and remains until the upload is complete.

Note: The log file notes if the upload is successful. If the upload fails, go back and ensure that you have the correct DECT password.

Resetting the module to default values

Now you must reset the module to default values.

1 You should still be in the **DECT Tools** section.

2 Click on the **Restore Default Firmware** link.

The Restore Default Firmware page appears.

Figure 14 Restore default firmware configuration

Your Location: BCM / Product Maintenance & Support / Maintenance Tools / DECT Tools / Firmware Restore Default
DECT Firmware Restore Default
Please enter your DECT Installer Password:
Restore Default Configuration

3 Beside **Please enter your DECT installer Password**, type: `insta*`

Note: *The Password listed here is the default. Your system settings may have been changed.

4 Click on the **Restore Default Configuration** button.

5 The restore default configuration operation begins.

Note: The log file notes if the upload is successful. If the upload fails, go back and ensure that you have the correct DECT password.

6 Once this step is complete, you are ready to set up the Business Communications Manager records and run the DECT Configuration wizard and time synch processes, as described in the following sections of this chapter.

Checking the Unified Manager handset DNs

The DECT handset is considered an ISDN S device. Assign the handset to DNs within the default ISDN and DECT range. Ensure that you do not assign handset DNs that have already been assigned to other ISDN devices.

Note: Default DECT module DNs:

- New 2.5 and greater Business Communications Manager: 597-624
- Upgraded 2.0 Business Communications Manager: 501-532

These defaults assume a system with a three-digit DN structure, and a Start DN of 221. If your system is different, use these numbers as guidelines to find the defaults to your system.

Note: If you need more DNs than are available in the default range, use the Companion DNs. Ensure these DNs are available before assigning them, then choose ISDN and DECT for the **DN Type** field.

Warning: It is imperative for the DECT module programming, that the DNs for your DECT handsets are within a range of DNs. If you assign handsets to DNs outside of a range, use the DN Renumber Wizard to renumber the DNs on the Business Communications Manager to create a range. Make sure you do not overwrite any DNs already in existence when you do this.

The issue: The DECT media bay module programming only has 12 lines to accommodate handset DNs, therefore, if you specify more than 12 individual DNs, and try to run the DECT Quick Start Wizard, the Wizard will fail.

Note: If you want to identify the handsets with the CO line number assigned to them, enter this number in the **Name** field for the DN record assigned to that handset.

To program the handset records in the Unified Manager, follow these steps:

1. Open the Unified Manager.
2. From the menu, click **BCM, Services, Telephony Services, System DNs, All ISDN/DECT DNs.**
3. Click on the DN number you want to assign to the handset.
4. Under the DN number, click **General**.
5. When the General screen appears, ensure that the **DN Type** displays ISDN and DECT.
6. Repeat for all handset DNs.
7. Refer to "Setting up the handsets" on page 43 for information about setting up the DN records.
8. When the records are set up, run the DECT Configuration wizard. Refer to "DECT Configuration Wizard" on page 46.
9. The configuration wizard also sets up the system to start subscribing handsets.
10. To turn off handset subscription (mobile recording), run the DECT Mobile Recording (Handset Subscription) wizard. Refer to "DECT Mobile Recording (Handset Subscription) Wizard" on page 60.
11. To check the DNs against the DECT module DNs, refer to "Listing mobiles (handsets)" on page 91.

Setting up the handsets

How you want to use the DECT handset will determine how you set up the handset DN record. This section describes the ways the handsets can be used.

Detailed configuration information is contained in the *Business Communications Manager Programming Operations Guide*.

The DECT cordless handsets either can be set to ring in tandem with a stationary set, or configured to act as stand-alone sets. As well, the handsets can be configured as target lines to accept direct inward dial (DID) calls.

This following sections explain the Unified Manager settings required for each type of scenario.

Stand-alone handset

A stand-alone set can be configured to only receive calls, or to both send and receive calls internally or externally.

Internal calls

The DECT interface comes with a set of default DNs. After the handsets are registered to these DNs, and the DNs are activated, the handsets can be used to make calls between sets.

After the DECT handset DNs are added to the Unified Manager, the handsets can be used to make and receive calls internal to the Unified Manager system.

External calls

The handset can be configured to have full send and receive capability to the public switched telephone network (PSTN), or, by using a target line, can be configured to receive calls only.

Assigning routes or lines

The Unified Manager automatically assigns all DNs with the default Pool A. This automatically allows calls through this line pool. This line pool can be deleted, and other pools added, depending on your requirements. Since the DECT handset does not have any line buttons, the user needs to know the line pool access codes or destination code that accesses any lines and line pools that are assigned to the handset record.

Follow these steps to assign a line pool to the handset record:

1. Open the Unified Manager.
2. On the navigation tree, click **BCM, Services, Telephony Services, System DNs, All ISDN DECT DNs, DN ##**, where DN is the DN of the DECT handset.
3. Ensure you have a line pool set up that you want to use.
4. Click **Line Pool Access** and click the **Add** button at the top of the column.
5. Click the line pool you want the handset to use to make and receive calls.
6. Repeat as necessary.

Assigning target lines

If you want the handset to receive incoming calls dialed using the handset DN, set up a target line for the handset. If you want the user to only receive calls on the handset, set up a target line and no other lines for the telephone.

Note: If you do not want the user to be able to dial out at all, ensure that no other lines or line pools are assigned to the handset.

1. Open the Unified Manager.
2. On the navigation tree, click **BCM, Services, Telephony Services, Lines, Target Lines.**
3. Click a **target line number heading that is not already assigned**.
4. Click on **Trunk/Line** data.
5. Click on **Received Number**.
6. Enter the handset DN number.

7 On the navigation tree, click **Services, Telephony Services, System DNs, All ISDN/DECT DNs, DN <handset DN>.**

8 Click on **Line Access, Line Assignment**.

9 Click the **Add** button at the top of the navigation tree.

10 Add the line number of the target line in **Line** field.

11 Click **Save**.

12 Click on the **Line <target line number>** heading.

13 Ensure **Appearance** is set to Appr. & Ring.

Assigning handsets to fixed telephone DNs

You can also associate the handsets with fixed telephones. With this feature, the handset rings whenever the fixed telephone rings.

1 Open the Unified Manager.

2 On the navigation tree, click **BCM, Services, Telephony Services, System DNs, All ISDN/DECT DNs, DN ##**, where DN ## is the DN you want to assign to the handset.

3 Click on the key beside Line access.

4 Click **Answer DNs**.

5 Enter the DN number for the fixed telephone you want to associate with the handset.

6 Press **<Tab>** to update the record.

7 Repeat this process for all handsets you want to assign.

Handset feature programming

The call features available to DECT handsets are described in "Handset system features" on page 67. Programming for these features is the same as for other Business Communications Manager telephones with these features. Refer to the *Business Communications Manager Programming Operations Guide* for instructions. Refer to the handset user manual for instructions on how to use the features.

About the DECT Wizards

These wizards will lead you through the necessary procedures to configure your DECT module and set up the module for subscribing the handsets.

If you need to change any of these settings after the wizards are run, refer to the specific procedure described in the following chapters.

DECT Configuration Wizard

Use this wizard to perform the initial configuration of a DECT module and to set up a base station to allow handsets to be subscribed to the system.

The wizard collects current information about the DECT settings from the Business Communications Manager, and sends them to the DECT module. None of this information displays on the screen, except for the ISDN or DECT DNs.

Warning: Use this wizard ONLY for initial configuration, as it wipes out any previous DECT module information.

Refer to "Using the Configuration Wizard" on page 48 for the steps about how to run the wizard.

Before you start

The following conditions are required before you run this wizard.

- The telephony (DNs and line access), routing information, and any line pool access coding must be configured on the Business Communications Manager.

Note: Any changes made after the wizard is run will not be reflected on the DECT module. This is an instance where you would need to go directly into the module settings and check or adjust the settings.

- The DECT module companding law has been correctly set for your region. Refer to "Configuring the module for µ-law" on page 39.
- The DECT module must have the factory default settings applied to it. If these have been changed in any way since the module was installed, you can reset the module through the wizard.
- You must ensure that the Business Communications Manager recognizes the DECT module. Refer to "Confirming the DECT module" on page 38.

You need to know the following information before you run this wizard:

• Do you want to reset the DECT module to the factory default settings?	**No Yes**
• What is the PARI value that you copied off the side of the DECT module before it was installed?	(PARI value)
• How do you want to identify the DECT module?	(Install Name)

- Which base station do you want to enable to allow terminal subscription?

  Refer to "Identifying base stations" on page 88 for more information about numbering.

- How many handsets will you be subscribing?
  Which DNs are assigned to these handsets in the Unified Manager?

- Do you want to enable **Call Waiting**?
  This setting allows you to turn the Call Waiting feature off or on for your DECT handsets.

  Choosing **No** disallows more than one call to the handset. Anyone trying to call a handset that currently has an active call will receive a busy tone.

  Choosing **Yes** allows a second call to alert on the DECT handset. The user on the active DECT handset hears a beep to indicate that a call is waiting.

  The user presses:

  - R*5 to answer the call
  - R2 to toggle between calls
  - R1 to return to the original call and disconnect the second call.

(base station) 6-0 6-1 6-2 6-3 7-0 7-1 7-2 7-3
(DN number) Yes (enable) No (no handset assigned)
(Enable Call Waiting) Yes (enable second call capability) No (disable second call capability)

Note: The Business Communications Manager provides up to 28 ISDN/DECT DNs. If you require more handsets, or if some of the DNs are already used for other equipment, you can change the DNs in the Companion range to ISDN/DECT.

This must be done before you run the Wizard, as the wizard only recognizes DNs with the ISDN/DECT label. Refer to "Checking the Unified Manager handset DNs" on page 42 for more information about default DNs.

Using the Configuration Wizard

Wizards are accessed through the Wizard button that appears on the first page of the Unified Manager.

Warning: Ensure there is no one else using the Unified Manager when you run wizards.

Follow these steps to fill out the wizard:

1. On the first page of the Unified Manager, click the **Wizards** button.

   A new page appears, displaying all the wizards that can be used for the Unified Manager.

2. Click on the **DECT Wizard** button for the task you want to perform.

Note: If the system does not recognize the DECT module, these buttons do not appear. Refer to "Before you start" on page 46.

3. On the first page (General), specify the DECT module information and the base station that you want to turn on to allow handset subscription. If you choose **None**, then handset subscription for all base stations is turned off.
4. Click the **Next** button to move to the next page.
5. On the second page, determine which DNs will be assigned to handsets.
6. Click the **Next** button to move to the third page.
7. On the third page, check the summary, which includes list of the DNs you selected.
8. Click the Apply button on the screen to invoke the wizard.

Setting up the module Time Synch

After you run the Configuration Wizard, you need to ensure that the module time is synchronized with the Business Communications Manager. Since the module time can drift out of synch, you can use this BRU tool to set up a schedule for daily time synchronization.

The time can also become unsynchronized if you perform firmware uploads. Also, if you change the password, you must re-establish the time synch schedule.

Follow these steps to set up a time synch schedule:

1. On the Unified Manager first page, click on the **Maintenance button**.

2. On the left menu of the maintenance site, click on **Maintenance tools**.
3. On the right frame of the Maintenance Tools page, click on the link under the **DECT Tools** heading. The DECT Tools page appears.
4. Click on the **Time Synchronisation** link.

   The Schedule a new DECT Time synchronisation page appears.

Figure 15 Time synchronisation page


Schedule a new DECT Time synchronisation:
How often do you wish to execute the DECT Time Synchronisation?
Every day
Today only
Only once, on the specified day of the month (e.g. 17):
Every month, on the following day(s) (e.g. 2,16,30):
Weekly, on the following day(s):
Monday
Tuesday
Wednesday
Thursday
Friday
Saturday
Sunday
Please enter a time (HH:MM - in 24hr format):
Please enter your DECT Installer password:
Schedule a DECT Time Synchronisation

5. Fill out the fields to indicate when you want time synchronisation to occur for the DECT module.

6 Beside **Please enter your DECT installer Password**, type: `insta*`

Note: *The Password listed here is the default. Your system settings may have been changed.

7 Click on the Schedule a **DECT Time Synchronisation** button.

Chapter 4
Installing the DECT base station

This chapter describes how to install the DECT base station according to the deployment site plan.

Ensure that you have a complete deployment and site plan before you start.

Installing base station hardware

This section describes how to install the base station hardware.

Use only qualified personnel to install or maintain the DECT radio base stations.

Special considerations

There are a number of considerations you need to take into account before you install a base station:

- Base stations must be positioned exactly where indicated on the site mapping plan. Any changes can affect transmission and reception.
- Avoid installing base stations on metallic surfaces or load-bearing walls made of reinforced concrete. If a metallic surface cannot be avoided, use a 50- to 80-cm extension bracket. Metal can impair transmission and reception.
- Place the base stations less than four meters from the ground. This makes it easier to maintain the base station and ensures correct radio coverage. Do not place stations lower than two meters.
- Do not install the base station behind obstructions, such as false ceilings.
- Always hang the base station in a vertical position.
- Leave at least 30 to 50 cm between co-located base stations.
- Install outdoors base stations in sealed cabinets.
- Leak-tight cabinets (reference DECT052) let you install DECT radio base stations outdoors without an external antenna. A mounting kit (reference DECT055) lets you secure the leak tight cabinet to a pole.

Note: Two base stations positioned side by side increase the channel capacity from four to eight possible simultaneous calls. Tandem base stations must be placed exactly 85 cm from each other. They also must be part of the same cell and trunk group.

- If you are using external antennas, refer to “Base station antennas” on page 56.

Installing the base station on the wall

Follow these steps to properly attach the base station to the wall.

1 Locate the base stations according to the site survey and deployment information.

Position the base stations at the exact point determined by the deployment survey. Moving the base station by one or two meters can harm transmission and reception.

Ground yourself with an antistatic grounding strap before performing procedures inside the base station housing.

2 Slide the cover of the base station upwards, then pull it away from the back panel.

Figure 16 shows the base station without the cover.

Figure 16 Base station with cover pulled away



3 Screw the back panel of the radio base station to the wall.

- Use two 3.5 x 25 mm wood screws with rawplugs. Insert the screws through the two holes located at the top end of the back plane of the base station.
- Install base stations vertically. Provide the required 5 cm (2-in.) clearance around the module for subsequent maintenance operations, as necessary.

Base station connections

Avoid sources of interference. Machines and wires can cause interference. Use Table 8 as a guide for laying out the Business Communications Manager cable to minimize the interference.

Table 8 Possible causes of interference

	Offices		Common areas	
Interference source	Power cables: total parallel length of 40 meters or less.	Fluorescent tubes	Neon signs, high interference sources[1]	Power cables: total parallel length
Installation distance	Stay at least 2 cm away.	Stay at least 30 cm away.	Stay at least 3 meters away.	Stay at least 30 cm away.
[1]Major sources of interference include industrial motors, inverters, rectifiers, transformers, high power cables, and so on. Cross these sources at a right angle to minimize the interference.				

1. Use individually screened pair cable between the base station and the Business Communications Manager.
2. **At either end, connect the two twisted pairs** to the center four pins in an RJ45 jack.

   You can use one of the following auxiliary equipment to make connections easier:

   — install a wall mounted RJ45 female connector and use a 10-cm long RJ45 ribbon cable

   — wire a long RJ45 male connector to directly connect the cable to the base station.

   The wire is a four-pair symmetrical, 6/10 shielded cable, series 278 or L122. Or you can use a category five certified cable, such as ATT cable P/N CPC 06. All cables must comply with ISO/CEI standard 11801.
3. Thread the cable through the upper cutout in the radio base station.

   Note: Make the following measurements if you use existing cables:

   Crosstalk at 100 khz (to detect pair mismatch and to check transmission performance)

   Near-end crosstalk at not less than 60 dB

   Attenuation at 10 khz (alpha < 6 dB)

   Loop resistance (R loop = R termination + R cable)
4. If you use external antennas, attach the cables as described in “Attaching external antennas to the base station” on page 57.

Note: Do not use an a.c. adaptor to connect the base station to a local power source unless power cannot be adequately provided through the Business Communications Manager cable.

5. Slide the cover back onto the back panel of the base station.
6. If your DECT module has been configured, you can now connect the base stations to the DECT module.

   If the DECT module has not yet been configured, refer to Chapter 3, “Configuring the DECT module,” on page 37 before you continue.

Connecting the base station to the system

After the DECT module has been installed in the Business Communications Manager, and has been identified and configured, you can plug the base station cables into the DECT module. This section describes the steps for correctly installing one or more base stations.

Note: This procedure should also be followed if the base station cables have been removed during maintenance procedures on the Business Communications Manager or the DECT module.

Checking the base station wiring

Before you connect the base stations and the DECT module, check the wiring and connectors with the tests described below.

- The base station requires an individually-screened paired cable for the connection between the station and the DECT module.
- Check the cabling between the DECT media bay modules and the base stations for continuity and match.

  These checks must be executed. Verify results for all connecting pairs before connecting the base station to the module.
- Check the RJ45 connector at the base stations and on the DECT module.
- Use impedance tests on the cable and base station assembly to trace the wires.
  The transmission and reception pairs measurements must match.
- Record the value measured for the transmission pair and deduct the distance between the radio base station and the DECT media bay module, using the information in Table 9.

Table 9 Cable lengths and resistances

Distance	0.6 mm cable	0.5 mm cable	0.4 mm cable
100 m	18.2 ohms	24.0 ohms	34.0 ohms
210 m	31.6 ohms	43.8 ohms	64.8 ohms
330 m	46.3 ohms	65.4 ohms	98.4 ohms
450 m	60.9 ohms	87.0 ohms	132.0 ohms
570 m	75.5 ohms	108.6 ohms	165.6 ohms
690 m	88.9 ohms	128.4 ohms	196.4 ohms
800 m	103.6 ohms	150.0 ohms	230.0 ohms

Attaching the base station to the module

There is a specific order and timing to connecting the base station to the DECT module. This section describes how to perform this process.

1 When the configuration is complete, connect the base station cables to the RJ45 jacks on the DECT media bay module. Refer to Figure 17.

Connect the cables sequentially, one at a time, waiting for each base station to begin the start-up phase before you connect the next base station cable.

Note: These RJ45 jacks correspond with the equipment numbers assigned to each base station on the DECT module. Refer to "Card Management" on page 75.

Refer to "Checking the base station wiring" on page 54 for wiring information.

Figure 17 RJ45 connectors on the media bay module



The base station has firmware installed at the factory. The DECT module checks this firmware load on startup and compares the version to what is on the module. If the versions differ, the DECT module automatically downloads the newer firmware to the base station during startup. This process takes several minutes.

Note: When you plug the base station into the port on the DECT module, the programming for that port is automatically assigned to the base station.

2 Monitor the LED on the base stations. Refer to Figure 18.

Figure 18 Status LED on outside of base station



Table 10 describes the possible LED conditions:

Table 10 Base station LED conditions

LED off	Radio base station is not powered.
LED on	Radio base station is disabled or downloading.
Slow blink	Radio base station is loaded. Link with DECT module is operational.
Fast blink	Radio base station is operating and communication is established between the two ISDN channels. This also occurs when all four channels are occupied.

3 When the base station LEDs are performing a slow blink, you are ready to subscribe the handsets.

Base station antennas

The base station comes with two internal antennas. However, you can remove these and connect the base station to one or two external antennas.

- **Internal antennas:** The base station has two quarter-wave antennas for diversity. The system automatically selects the best one.
- **External antennas:** Use a kit to add an external antenna. Where only one antenna is used, you can override the diversity function through the user interface.

  The *Business Communications Manager Installation and Maintenance Guide* provides details about external installation and regulations.

Three types of external antennas can be used, as shown in Table 11. You also require an adapter (HT6176A).

Table 11 External antennas

Part number	Description
MA431X23	Omnidirectional with extension cord
MA431X24	Omnidirectional with extension cord
MA821X12	Bi-directional with 50 cm cable and molded TNC male connectors
Do not add extra cables to Bi-directional antenna P/N MA821X12. Adding extra cables can hurt the gain and directivity of the antenna. Place the antenna as close as possible to the base station. **Remotely site the other two antennas** (P/N MA431X23 and P/N MA431X24). For more information, please refer to the installation manual provided with the connecting kit for outdoor antennas.	

Attaching external antennas to the base station

This section describes the steps for attaching the cables from an external antenna to the antenna ports on a base station.

1 Remove two internal antenna cables by sliding them up and away from the connectors on the board.

2 Remove the black antenna plate. Refer to Figure 19.

Figure 19 Removing the internal antenna plate



3 Secure cables to external antenna connectors ANT1 and ANT2
Use ANT1 if there is only one antenna.

4 Connect the external BNC connector for each antenna.

5 Slide the cover back onto the back panel of the base station.

Refer to “External antenna settings” on page 75 to configure the DECT module to access the external antennas.

Chapter 5
Subscribing DECT cordless handsets

This chapter describes how to subscribe the cordless handsets. Subscription allows the handset to communicate with the DECT system. You must have at least one active radio base station to complete the subscription procedure.

Note: These steps are specific to the C4010 and C4020 handsets. However, all brands of handsets have a similar process. If your handset does not have a similar screen setup to the steps below, refer to the user manual enclosed with your set for specific instructions about entering the registration mode for that set.

Figure 20 provides an overview look at the process of subscribing the handsets.

Figure 20 Process for subscribing the cordless handsets


Set base station to allow access
You must set up one base station to allow mobile recording.
After you have subscribed the new handsets, ensure that you return the mobile recording field to No.
Refer to "Confirming base station readiness" on page 64.
Subscribe the handsets
From each handset, enter the base station you want to key the handset to, and enter the handset password. Refer to "DECT Mobile Recording (Handset Subscription) Wizard" on page 60.
Reset the base station record
Turn off mobile recording for the base station to prevent any unknown handsets from subscribing to the system.
Refer to "Resetting the base station" on page 63.
Test the handset
Test the handset from various locations to ensure that it works with all the base stations.
Refer to "Setup test" on page 66.
Handset features
Refer to "Handset system features" on page 67 for a list of the main system features available to the handset. Refer to your handset guide for instructions on using the features.

Base station recording status

Before you attempt to subscribe handsets to a new DECT module, ensure that the system can accept them.

This procedure assumes that you ran the DECT Configuration Wizard, and set up the DN records in the Unified Manager.

Before you can subscribe a handset to the system, the DECT module must be set to receive subscriptions. You can use the DECT Mobile Recording (Handset Subscription) Wizard to do this. You can also use this wizard to turn off recording on the DECT module after you finish subscribing your handsets.

DECT Mobile Recording (Handset Subscription) Wizard

Use this wizard to turn on a base station to allow handset subscription, which is described in Chapter 5, “Subscribing DECT cordless handsets,” on page 59.

You can also use this wizard to turn off mobile recording when you have completed the handset subscriptions.

Note: When one base station is set to on, then all other base stations are off.

Do not use this wizard until all other DECT module parameters are set.

Before you start

You need to know the following information before you run this wizard:

- What is the system password?

  Default: `insta`
- Which base station do you want to enable to allow terminal subscription?

  Refer to “Identifying base stations” on page 88 for more information about numbering.

  Note: Pick the base station that is in the most convenient proximity to where the handsets will be subscribed.

(Password)			
(base station)			
6-0	6-1	6-2	6-3
7-0	7-1	7-2	7-3

Filling out the Mobile Recording (Handset Subscription) Wizard

Follow these steps to use the wizard:

1 On the first page of the Unified Manager, click the **Wizards** button.

A new page appears, displaying all the wizards that can be used for the Unified Manager.

2 Click on the **DECT Mobile Recording Wizard** button.

Note: If the system does not recognize the DECT module, the DECT wizard buttons do not appear. Refer to "Confirming the DECT module" on page 38.

3 On the first page, enter the system password, if there is one.

4 Choose the base station you want to turn on for mobile recording (handset subscription).

5 Click the **Next** button to move to the next page.

6 If the summary is correct, click the **Apply** button.

Turning off mobile recording

When you are finished subscribing the handsets, run the wizard again and select **None** in the **Mobile Recording (Handset Subscription)** field to turn mobile recording off.

Subscribing DECT cordless handsets

The procedure in this section describes how to activate the handset to communicate with the Business Communications Manager.

Ensure that mobile recording has been activated on the DECT module. Refer to "DECT Mobile Recording (Handset Subscription) Wizard" on page 60.

If you attempt to subscribe a handset and the system will not acknowledge it, use the procedure in "Confirming base station readiness" on page 64 to view the state of the base station you are trying to subscribe the handset to.

Handset buttons

Table 12 provides a quick preview of the function buttons on the handset. You use these buttons in the procedures in this chapter.

Table 12 Buttons used during handset subscribing

Handset icon	Function
	Use to scroll through menus.

Table 12 Buttons used during handset subscribing (continued)

Handset icon	Function
▶ ◀	Use to select and confirm menu items displayed at bottom of screen.
C	Press to clear.

Subscribing a handset

To subscribe a handset, use the handset you want to subscribe, ensure you are within range of the base station you turned on, then follow these steps:



1 Press the ◀ button under Menu until you find **Personalize/Last Numbers**.

2 Press the ▶ button to open the Personalize menu

3 Press the ◀▮▶ key until `Declare Base` appears.

4 Press the ◀ button under Declare



This message appears on the handset.

A blinking number indicates the default.

5 Press ◀ to confirm the default

Note: 1 is the common default. If another number is blinking, the handset has been assigned to another system. If the user only needs access to this DECT system, you can unsubscribe the 1 position. You can then subscribe the 1 position to the current DECT system. For instructions about how to unsubscribe a handset, refer to "Unsubscribing the handset" on page 116



This message appears on the handset.

6 Enter the handset code using the handset digital keypad

Note: This code is an eight-digit combination of the handset DN and the DECT handset password.

Enter the set DN, then add enough digits of the password to make eight digits.

For example: If you have five-digit DN 67890 and a password of 12345, the Code would be 67890123.



If this message displays (three seconds), the mobile is registered.



If this message appears, the handset is not subscribed.

The display returns to `Enter code`.

Troubleshooting note: If all your programming appears to be correct, but the handset will not register, try the following:

1. Remove the battery cover and pull the battery out.
2. Place the battery back into the housing and replace the cover.
3. Try subscribing the handset again.

Resetting the base station

After you have subscribed or deleted handsets, go back into the Unified Manager and turn off mobile recording for the base station. Use the DECT Mobile Recording (Handset Subscription) wizard to perform this procedure. Refer to "DECT Mobile Recording (Handset Subscription) Wizard" on page 60.

If you are not sure of the state of the base station, follow the procedure in "Confirming base station readiness" on page 64, and check the state of the base station.

Checking handset status

If you want to confirm that the handsets are entered into the DECT system, you can view the list through the DECT module interface.

Follow these steps to check the handset status:

1. Open the Unified Manager.
2. Click **Resources, DECT**.
3. Under the Tools menu, click **Launch Maintenance Console**.
4. When the screen says: `Connected to <IP address>`, press <CTRL p>.

   The Main maintenance screen appears.
5. From the main menu, type **4** <ENTER> (Open Operation and Administration).
6. Type **6** <ENTER> (Display Statuses)
7. Type **3** <ENTER> Status of Data Links record. Refer to Figure 21.

Figure 21 Define Radio Base Station XX DECT screen

```
EQT NO.     TYPE        DN      STATUS      NO.LC
-------------------------------------------------------------------------------
AFISER      SERVER      010     FREE
SERVTL      SERVER      011     FREE
KITAXE      SERVER      012     FREE
SAESAE      SERVER      013     FREE
MUFACT      SERVER      014     FREE
SERV        SERVER      015     FREE
SERGIC      SERVER      016     FREE
SRVRHM      SERVER      017     FREE
DEBUG       SERVER      018     FREE
TELBOR      SERVER      019     FREE
ERF         SERVER      020     FREE
6-0         PLC 80      99900   DISCONNEC
6-1         PLC 80      99901   DISCONNEC

Note: card numbers 6-2, 6-3, 7-0, 7-1, 7-2, 7-3 are on page 2 <ESC m>
```

8 Telbor status changes from **Free** to **Incomm 1**.

9 <ESC m> to view the base station activity.

Confirming base station readiness

If you turned on base station recording with the Wizard, but you are unable to subscribe handsets to the DECT module, use this procedure to check the state of the base station.

1 Open the Unified Manager.

2 Click **Resources/DECT**.

3 Under the Tools menu, click **Launch Maintenance Console**.

4 When the screen says: `Connected to <IP address>`, press <CTRL p>.

5 You will be prompted for a password. (Default=`insta`)

The Main maintenance screen appears.

6 Type `1` <ENTER>. The Telephony Management screen appears.

7 Type `8` <ENTER>. The Wireless Management screen appears. Refer to Figure 22.

Figure 22 Wireless Management Menu menu

```
1  TOPOLOGY
2  RESOURCES
3  MOBILES

ENTER YOUR CHOICE                    ..
```

8 Type `2` <ENTER>. The Wireless:Resources menu appears. Refer to Figure 23.

Figure 23 Wireless Resources Menu menu

```
1 TRUNK GROUP NAMES
2 TRUNK GROUP DEFINITION
3 BASE STATION ALLOCATION
4 BASE STATION DISPLAY
5 COVERAGE DISPLAY

ENTER YOUR CHOICE                    ..
```

9 Type `3` <ENTER>.

The Base Station Selection menu appears. Refer to Figure 24.

Figure 24 Base Station Selection menu

```
BY EQUIPMENT NUMBER          ..
OR BY ITS TRUNK GROUP        ..............
OR BY ITS CELL               ...............
OR BELONG TO AREA            ...............
```

10 On the first line, type `60` <ENTER>.

Note: These numbers correspond to the RJ45 jacks on the face of the DECT module, from left to right: 73, 71, 72, 70, 63, 62, 61, 60. These connections correspond, in turn, to ports on cards inside the module. All handsets are subscribed to the module and not the card port, therefore, you can subscribe all the handsets through one open port.

The Define Radio Base Station 6-0 DECT Access screen appears. Refer to Figure 25.

a **New system:** Status: **disabled**, Mobile Recording Allowed: *Yes*

Existing system: Status: **In service**; Mobile Recording Allowed: *No*

b **New system:** Move your cursor to Status, and use the space bar to find *In Service*.

The display shows that the base station is downloading. This takes from 30 seconds to 10 minutes, depending on whether the base station needs to update the firmware.

Figure 25 Define Radio Base Station XX DECT screen

```
DEFINE RADIO BASE STATION 6-0 DECT
RAD. BASE DEFIN. 6-0 DECT
STATUS Disable                          .........
RAD. BASE TYPE                          4 CHAN.
BELONGS TO TRUNK GROUP                  [Trunk Group
Name)
MOBILE RECORDING ALLOWED                YES
FRAME TS 0->11 AFFECTATION              111111111111
TS NO MODIFICATION ..
0->9 FREQUENCY ALLOCATION               111111111111
- FREQUENCY NO MODIF
ANTENNA SELCTION                        AUTOMATIC
SYNCHRONIZATION                         VIA BIT FRAME
S
DISTANCE FROM MASTER BS                 D<100
METERES
TYPE OF BUS                             SHORT
```

c Exit the screen and wait for the base station to complete the download. If you go back into the screen, Status reads: *In Service*.

11 Subscribe the handset.

Refer to "Subscribing a handset" on page 62.

Setup test

When you have completed handset subscription, or any change to the DECT system, check that the system is operational.

1 Check that the base station LED indicates that the module is in service (LED blinks slowly). If the LED is on but not blinking, the module is downloading new information from the Business Communications Manager. This can take as long as 10 minutes.

2 Check the system operation.

Perform the following operations in order to test the DECT service.

a Locate four handsets near separate base stations.

b Dial each set from another cordless handset.

c Ensure that the handsets are able to talk to each other.

d Check the system for general operation. Refer to Table 13.

Table 13 Troubleshooting the preliminary operations

Problem	Solution
Communication with the handset is interrupted while moving around between base stations,	Re-establish the communication from an operational base station, then continue checking the other base stations.

Table 13 Troubleshooting the preliminary operations (continued)

Problem	Solution
Communication cannot be established from a radio base station:	Check the configurations

Handset system features

The cordless handset can perform the following features:

- twin to a fixed set to allow remote reception of calls
- make and receive calls from the handset, within the range of the system the handset is subscribed to as an independent set
- transfer and conference calls from and to the handset

Note: This feature uses two of the available eight lines per DECT when the handset is the primary and the other two calls are non-DECT calls.

Conference calls originated from the handset are limited to one hour.

- display an internal caller by name, and an external caller by number or name, depending on how the external line is set up.
- query the voice mail system using the mail extension or the Message Waiting button
- call forward calls, and cancel call forward, to another set, to voice mail, or to an external number
- determine when a call gets forwarded: all calls, on busy, or if call is not answered
- make a second call while a call is in progress
- shuttle between two calls
- roam between DECT cells (handset-specific)
- call waiting indication if a call is received while the handset is busy on another call.

Note: The third call into a cordless handset receives a busy tone, depending on the type of call (internal/external), the type of line, and the DND on busy setting. If the portable user cannot be located, call capture rules apply.

Note: Refer to the *Business Communications Manager Programming Operations Guide* to configure these features for each handset DN.

- enbloc and overlap dialing is supported, as well as memory dialing
- Hunt groups: If more than four handsets are deployed in a hunt group, ensure that no more than four are configured to the same base station.

Message Waiting Indicator (MWI)

DECT handsets have the ability to access mailboxes for both internal, stand-alone systems, and external voice mail systems accessed over a private network.

To initialize and set up the connection, you must directly dial the voice mail system through the handset and set up or change the account as required. Your voice mail administrator provides the number and your account access.

Programming the MWI lamp button

When a message occurs for a handset, the MWI lamp on the handset lights.

This button must be programmed with the voice mail access code so the user can press the button and be automatically connected to the voice mail system. The voice mail field must be set to *65 to allow the MWI feature (*65) to work.

To set up the feature, on the handset:

- Go to Menu/Personalize/VoiceMail/**VoiceMail Nr** and enter ***65**.
- Go to Menu/Personalize/VoiceMail/Access Nr and ensure that the field is blank.

When all messages have been retrieved, the MWI button lamp goes off. The user then presses the MWI button again to release the call and the user hears a reorder tone.

Twinning features

These are the features and anomalies that occur when you twin a DECT handset to a desk telephone, or vice versa.

- Busy Lamp Indication: if the desk telephone has a BLI, the lamp indicates the current status of handset.
- Ringback issues occur if the DECT handsets do not have Call Forward No Answer configured.

CallPilot programming

If CallPilot is the voice mail system being used, ensure that the administrator includes the handset DN as the alternate DN for the desk set with which the DECT handset is twinned.

If the DECT handset is being used as a stand-alone set, then the CallPilot set up is the same as for any other Business Communications Manager set.

Note: Mailbox access is the only Business Communications Manager voice mail application that is accessible from the handset.

Auto-answer issues

(security issue)

If your handset is set to Auto-Answer, you can be opening yourself to security issues. If your cordless DECT handset is set to Auto-Answer, your handset opens the line to the caller, whether you activate the handset or not. This occurs even if your voicemail is set to automatically go to voice mail after a number of unanswered rings,

Refer to your handset documentation for the steps required to turn Auto-Answer off on any handsets where this feature can be a concern.

Receiving a page

DECT portables cannot receive pages. However, you can initiate a page from the DECT handset to any other wired system telephones, using the page feature codes.

Feature code	Feature	Description
	Page - General	Allows the user to page all sets.
	Page - Zone	Allows the user to page a specific zone which is identified within the Button programming.
	Page - Speaker	Allows the user to page through the speaker on a specific telephone.
	Page - Speaker and zone	Allows the user to page through the speaker on telephones in a specific zone, which is identified within Button programming.

Note: If you try to send a page to a DECT handset from a standard Business Communications Manager digital telephone, there is no indication that the page is not going through. Also, there is no indication on the DECT handset that someone is trying to page the handset.

Roaming

Roaming allows the DECT cordless handset to hook on to an authorized radio base station that provides the best possible signal.

Note: This feature is only available to DECT handsets.

A handset can also turn to idle (standard status: detached). In this state it is considered non-located. When the handset makes a call, it automatically returns to the located status.

Whenever an attempt is made to call a non-located handset, the call:

- forwards to the prime set for the line, if declared (recommended solution)
- receives a busy tone if no prime set is assigned

When the handset is turned on, DECT cordless handset scans the radio-frequency spectrum and measures the signals transmitted by various base stations in the area. If the handset receives a stronger signal during operation, the handset processes the information (RFPI, SARI list, etc.) sent by the prevailing radio base station. It checks if it can hook on to it, which depends on access rights.

The following occurs:

- If the access is permitted, the handset compares the radio base station RFPI to the LAL value, which is generated upon registration. It uses this calculation to determine if the radio base station belongs to a new roaming area (cell).
- If the comparison indicates that the location area has changed (with no communication established), the handset sends a roaming request to the radio base station. If the radio base station accepts, the handset remains synchronized to this base station for on-going analysis of the signaling channel (cell selection). At this stage, the handset is attached to this radio base station.

With communication established, the handset initializes an external hand-over in order to keep the communication established when the radio base station changes.

Note: In case of access restrictions, the DECT module can refuse a cell change. If so, the handset waits a certain time before making new attempts.

Roaming on outgoing calls

Roaming is activated from the handset.

A handset sends a request for roaming to the DECT module in the following circumstances:

- when the registration procedure completes
- whenever the handset is turned on
- when external hand-over occurs
- whenever the handset changes cells

The handset uses the exchange protocol on the radio interface to understand that the stronger signal it is now connecting to belongs to a roaming zone. Further, the signal indicates it is a different base station from the one the handset was attached to.

The DECT module updates its routing tables and stores the (site-based) number of the cell occupied by this handset.

Direct Inward Roaming

Incoming calls route to this handset when its site and cell numbers are specified.

Chapter 6
Programming DECT module defaults

Use the DECT Configuration Wizard to set up the DECT module. However, if you need to check any of the DECT module parameters after the initial configuration of the module, you can go to individual records on the module to check or change settings. For instance, if you want to assign a new password.

This chapter describes the DECT interface menus that define the basic system parameters for the DECT module. A new DECT module comes with a set of defaults. Use these menus to check that the defaults are set correctly for your system or adjust the settings, as required.

You can access these menus through **Launch Maintenance Console** on the Unified Manager Tools menu when you select a DECT module record.

Figure 26 provides a map of the default settings you need to check.

Figure 26 DECT interface, system management


Launch Maintenance Console
Enter the DECT interface through the Unified Manager Launch Maintenance Console.
Refer to "Opening the Maintenance Console" on page 72.
Check passwords
Check the system and handset passwords.
Refer to "DECT and handset passwords" on page 73.
Check language setting
Confirm that the interface is in the language you require.
Refer to "Language Management" on page 74.
Confirm card ports
Confirm that the DECT module C8 card is set up correctly.
Refer to "Card Management" on page 75.

Opening the Maintenance Console

To access the DECT module interface, use the maintenance console application in the Unified Manager. These steps describe the process of launching the application.

1. Enter the Unified Manager.
2. Click **Resources, DECT**.
3. Choose the Maintenance Selection tab.
4. Ensure that the DECT module has been chosen.
5. Under the **Tools** menu, click **Launch Maintenance Console**.
6. When the screen says: `Connected to <IP address>`, press <CTRL p>.
7. You will be prompted to enter a password. (Default=`insta`)
8. Type `10`.

   The Main maintenance screen appears. Refer to Figure 27.

Figure 27 Main DECT maintenance menu

```
1    TELEPHONY MANAGEMENT
2    DATA MANAGEMENT
3    SYSTEM MANAGEMENT
4    OPERATION ADMINISTRATION
5    INSTALLER DATA

ENTER YOUR CHOICE                ..
```

System Management

Use the System management menus to:

- set a password for your DECT system and the handset
- select a default language, if required
- select ports on the DECT boards.

1. On the main menu, enter `3` <RETURN>.
2. Enter the installer password. (Default: `insta`)

   The System Management screen appears. Refer to Figure 28.

Figure 28 System Management menu

```
1    DATE AND TIME MANAGEMENT
2    CARD MANAGEMENT
3    RAM MESSAGE RECORDING
4    TERMINAL MANAGEMENT
5    PASSWORD MANAGEMENT
6    PARAMETER MANAGEMENT
7    SOFTWARE LOCK MANAGEMENT
8    INTEGR. BUFFER MANAGEMENT

ENTER YOUR CHOICE                ..
```

DECT and handset passwords

You can control the access to the DECT program using passwords. The system default password is *insta*. You can add, change, or delete the password, as required.

1 On the system management screen, type **5** <RETURN>.

The Password Management screen appears. Refer to Figure 29.

Figure 29 Password Management menu

```
MANAGEMENT PASSWORD
READ-PROTECTED WRITE-PROTECTED    DONNE
- LAST ACCESS ON AT 01 01 80 00 00
READ NORMAL. WRITE NORMAL.        DONNE

ADMINISTRATION PASSWORD
READ. CHARGE COUNTER + LOG RESET  SUIVI
- LAST ACCESS ON AT 01 01 80 00 00
READ. CHARGE COUNTER RESET        SUIVI
INSTALLER PASSWORD                INSTA
- LAST ACCESS ON AT 31 10 00 14 27
PASSWORD RECORD. MOBILE           12345
```

2 On the **Installer Password** line, enter a new password, or leave it blank.

3 On the **Password Record. Mobile** line, enter a registration number.

Note: This number is used as part of the registration key for the handset.

4 Press <CTRL j> to return to the System Management menu.

Note: If you change the DECT Administrator password, you must delete the scheduled time synch task. To delete the task, click the **Schedule** link on the BRU window to display the task, then click the **Delete** button.

After the task is deleted, you need to re-establish the time synch schedule. For details, refer to "Setting up the module Time Synch" on page 49.

Language Management

If the menu system is not in the language you want, you can change the default language. If the menu is in the language you want, skip this section.

1 On the System Management menu, type `6` <RETURN> (Parameter Management).

The Parameter Management screen appears. Refer to Figure 30.

Figure 30 Parameter Management menu

```
MULTI-COMPANY MANAGEMENT              NO
MULTI-SITE MANAGEMENT                 NO
OPERATOR GROUP AUDIT ACTIVATED        NO
TYPE OF THE WIRELESS MANAGEMENT       DECT
CONSOLE TIME-OUT (SECONDS)            600
CURRENT LANGUAGE                      LANGUAGE 2
INSTALL. NAME MC 6501 C .....

NUMBER OF RECORDS     (current)   (requested)
- TELEPHONY TYPE      356         356
- DATA TYPE           10          10
- SERVICE TYPE        10          10
- MONITORING TYPE     24          24
```

2 Use the space bar to select the correct language.

3 Press <CTRL j> to return to the System Management menu.

Card Management

The Card Management menus define the status of the cards on the DECT module.

This menu is accessed from the System Management screen.

Only two of the seven cards on the DECT module relate specifically to DECT lines. These are cards 6 and 7, which each contain configurations for four ISDN-S ports. These ports are also referred to as equipment numbers.

Orientation Note: Each card has four ports	
Card 6 supports ports 6-0, 6-1, 6-2, 6-3	Card 7 supports ports 7-0, 7-1, 7-2, 7-3
These numbers correlate directly with the Equipment number found in these menus, and in the Unified Manager. In turn, they also match the port jacks on the DECT module.	

Ensure that the cards display the correct type of line. Also ensure they are `In Service` before you assign DECT handsets to the lines.

External antenna settings

If your base stations have external antennas, use the following steps to set the DECT interface to find them.

1 Enter the DECT interface and navigate to the Wireless Resources menu.

Refer to "Opening the Maintenance Console" on page 72 if you are not already in the DECT interface.

The Wireless Resources screen appears. Refer to Figure 31.

Figure 31 Wireless Resources menu

```
1    TRUNK GROUP NAMES
2    TRUNK GROUP DEFINITION
3    BASE STATION ALLOCATION
4    BASE STATION DISPLAY LIST
5    COVERAGE DISPLAY

ENTER YOUR CHOICE                ..
```

2 On the The Wireless Resources menu, enter **3** <RETURN>.

3 Enter the port number the base station is connected to (60, 61, 62, 63, 70, 71, 72, or 73), then press <ENTER>.

The screen called Define Radio Base Station (station/equipment number) DECT Access appears. Refer to Figure 32

Figure 32 Base station screen

```
RAD. BASE DEFIN. (station/equipment number          DECT
STATUS IN SERVICE                                   .............
RAD. BASE TYPE                                      4 CHAN.
BELONGS TO TRUNK GROUP                              [Trunk Group Name]
MOBILE RECORDING ALLOWED                            NO
FRAME TS 0->11 AFFECTATION                          111111111111
TS NO MODIFICATION ..                               ..
0->9 FREQUENCY ALLOCATION                           111111111111
- FREQUENCY NO MODIF                                .
ANTENNA SELECTION                                   AUTOMATIC
SYNCHRONIZATION                                     VIA BIT FRAME S
DISTANCE FROM MASTER BS                             D<100 METERS
TYPE OF BUS                                         SHORT
```

4 Scroll down to the **Antenna Selection** field and change the setting to **ANTENNA 1 or ANTENNA 2**.

5 Press <CTRL u> to return to the main menu.

Chapter 7
Programming numbering plans and base stations

This chapter describes the DECT interface menus that define how the DECT will handle calls through the base station. Figure 33 provides an overview of the steps required.

If you ran the DECT Configuration wizard, this information is automatically configured. This section describes how to check each setting using the Maintenance Console.

Figure 33 DECT interface, trunk and cell management


Launch Maintenance Console
Enter the DECT interface through the Unified Manager Launch Maintenance Console.
Refer to "Opening the Maintenance Console" on page 72.
Identify the DECT module
Enter the PARI value to identify the DECT module to the system.
Refer to "Setting DECT PARI values" on page 79.
Set up numbering plans
Set up the outgoing and incoming number plans.
Refer to "Numbering Plans" on page 80.
Name cells
Name the cells where the base stations will be allocated.
Refer to "Cell names" on page 84.
Name and assign trunks
Name the trunks and assign them to cells.
Refer to "Managing Logical Trunks" on page 85.
Enable base stations
Enable each base station. Prepare one base station to receive handset subscription. Refer to "Managing Logical Trunks" on page 85.

Planning your DECT settings

To plan what you need to enter, refer to your DECT deployment plan. You also require access to the Business Communications Manager information.

Use Table 14 to identify the cells, trunks and base station allocations.

Table 14 Identifying cell, trunk and base station assignments

Cells	Trunks assigned	Base stations
Example: Cell CGCL22	two trunks are assigned 60CGTR22, 61CGTR22	connected to these base stations base station 1, base station 2

Use Table 15 to identify the numbering plan entries for your system.

Table 15 Identify the outgoing and incoming numbering codes for your system

DN length =		
Outgoing DNs and codes		**Incoming DNs**

Setting DECT PARI values

DECT systems require a unique identity number to enable handset subscription. This PARI value number is located on a label on the module.

Follow these steps to enter the PARI value:

1 Enter the Maintenance Console and find the Wireless Management menu.

Refer to "Opening the Maintenance Console" on page 72.

2 Navigate to the Wireless Management menu. Refer to Figure 34.

Figure 34 Wireless Management menu

```
1 TOPOLOGY
2 RESOURCES
3 MOBILES

ENTER YOUR CHOICE              ..
```

3 On the Wireless Management menu, type **1** <ENTER>.

The Wireless Topology menu appears. Refer to Figure 35.

Figure 35 Wireless Topology menu

```
1    NAMES OF CELLS
2    DECT PARAMETERS

ENTER YOUR CHOICE..
```

4 On the Wireless Topology menu, type **2**<ENTER>.

The DECT parameters screen appears. Refer to Figure 36.

Figure 36 DECT parameters screen

```
PARI VALUE 0                    XXXXXXXXX
RANDOM VAL RECORDED             12.....
RS VAL RECORDED                 34.....
DIR. BEGINNING ASSIGNED TO PLL  999
```

5 Type <CTRL j> three times to return to the Telephony Management screen.

Telephony Management

Use the Telephony Management menus in the main screen to manage the base stations, handsets, and external trunks. Refer to Figure 37.

Figure 37 Telephony Management menu

```
1    EXTENSION DATA
2    EXTERNAL TRUNK DATA
3    NUMBERING PLAN
4    OPERATOR MANAGEMENT
5    CALL DISTRIBUTION MANAGEMENT
6    CALENDAR MANAGEMENT
7    PARAMETER MANAGEMENT
8    WIRELESS MANAGEMENT

ENTER YOUR CHOICE                ..
```

Numbering Plans

The Business Communications Manager and DECT module dialing plan and call routing must be compatible to allow full service to the DECT handsets.

Do not change any DECT settings unless you are familiar with the Business Communications Manager number plan.

Outgoing Numbering Plan

The list accessed with this procedure contains all the extensions you want to pass to the Business Communications Manager. It excludes the DN range numbers for the DECT cordless handsets.

1. From the main DECT menu, type `1` <RETURN>.
2. From the Telephony Management menu, type `3` <RETURN>.

   The Numbering Plan menu appears. Refer to Figure 38.

Figure 38 Numbering Plan menu

```
1    DIRECTION NAMES
2    USER NUMBERING PLAN
3    INCOMING CALL NUMBERING PLAN
4    COMMON ABBREVIATED NUMBERS
5    DISPLAY ABBREVIATED NUMBERS
6    BARRED NUMBERS
7    SPECIAL ABBREVIATED NUMBERS
8    CALL REROUTING MANAGEMENT

ENTER YOUR CHOICE                ..
```

3 Type 2 <RETURN>.

The User Numbering Plan Menu appears. Refer to Figure 39.

Figure 39 User Numbering Plan menu

```
1   ACCESS TO EXTENSIONS
2   ACCESS TO FEATURES
3   ACCESS TO PUBLIC EXCHANGE
4   ACCESS TO DIRECTIONS
5   SUFFIX DEFINITION
6   DISPLAY NUMBERING PLAN
7   RESET NUMBERING PLAN

ENTER YOUR CHOICE                ..
```

TIP: To display the numbering plan that is currently in effect, type 6 <RETURN>.

4 On the User Numbering Plan menu, type **4** <RETURN>.

5 Ensure that this list contains all the extensions you want to pass to the Business Communications Manager.

Note: This list excludes the DN range for the DECT handsets.

a To change an entry, delete the existing entry, then add the new entry.

b To add a new entry, go to a blank line and add the entry.

Figure 40 shows a couple of examples.

— 9(*) = user dials 9, then any number of digits after (external line)

— 0(1) = user dials 0 (operator)

— 5(5) = user dials a five-digit extension starting with 5. (50000 to 59999)

Figure 40 DECT directory numbers

```
SPECIFIC NUMBERS
1                    9(*).....
2                    0(1).....
3                    5(5).....
etc.                 .....
```

6 Press <CTRL j> to return to the Users Number Plan.

User Numbering Plan

The User numbering plan lists the range of handset extensions. This list provides handset-to-handset access on the network.

Follow these steps to add or change the User Numbering Plan entries:

1 On the User Numbering Plan menu, type `1` <RETURN> (Access to Extensions).

The Local Dialing list appears. Refer to Figure 41.

Figure 41 Local Dialing List

```
NUMBER OF DIGITS              3
NUMBER OF DIGITS TO DELETE    0
RANGE 1                       597-9
RANGE 2                       66-1
RANGE 3                       620-4
etc.
```

2 Ensure that Number of Digits corresponds to the DN length used by your Business Communications Manager system.

a To change the number, delete the current entry using the <Delete> key on your keyboard.

b Enter the new number, then press <RETURN>.

3 Range 1-12: enter the ranges of handset extensions.

This allows you to access other handsets on the network from your handset.

a Delete any existing range numbers if they are incorrect.

b Add the new range(s) of DNs (597-624).

Syntax: The syntax you use to enter numbers depends on the entry in the Number of Digits line. Refer to Table 16 for the default ranges. Adjust the numbers to fit the DN range on your own system.

Table 16 DECT defaults:

Default Range (597-624)	Range	3-digit entry
597-599	Range 1	597-9
600-619	Range 2	60-1
620-624	Range 3	620-4

Example: If you specified 3 for the number of digits, enter the numbers as follows:

- To enter the range 500-529, enter 50-2 for Range 1
- To enter 530 to 532, enter 530-2

4 Press <CTRL j> until you return to the Telephony Management screen.

Incoming Call Numbering Plan

The list you access with this procedure determines what calls to the handset are allowed. Ensure that the Default Number of Digits in this list is the same as the DN length entered in your Business Communications Manager and the DECT local dialing list.

1 From the Numbering Plan menu, type `3` <RETURN>.

The Incoming Call Numbering Plan menu appears. Refer to Figure 42.

Figure 42 Incoming Call Numbering Plan menu

```
1   INTERNAL DIALING
2   ACCESS TO PUBLIC EXCHANGE
3   ACCESS TO DIRECTIONS
4   DID CORPORATE NUMBERS
5   DISPLAY NUMBERING PLAN
6   RESET NUMBERING PLAN

ENTER YOUR CHOICE                ..
```

2 Type `1` <RETURN> (Internal Dialing).

The Incoming plan: internal numb. list appears. Refer to Figure 43.

Figure 43 Incoming plan: Internal numb.

```
DEFAULT NUMBER OF DIGITS                          3
NUMBER OF DIGITS TO DELETE                        0
SPECIFIC NUMBERS
1                                    ..............
2                                    ..............
3                                    ..............
4                                    ..............
5                                    ..............
6                                    ..............
7                                    ..............
8                                    ..............
REMOTE MAINTENANCE MODEM NUMBER           ........
OPERATOR CALL                             ........
CALL NUMBER OF TEST DEVICE                ........
```

3 Ensure that the Default Number of Digits is the same as the DN length entered in your Business Communications Manager and the DECT local dialing list. Refer to Figure 41.

4 Press <CTRL j> until you return to the Telephony menu.

Wireless Management

Manage the cells and virtual trunks through the Telephony Management/Wireless Management/ Topology menu.

Cell names

Each base station is part of a cell. Use this procedure to identify the cells in your system.

1. At the main menu, type `1` <ENTER>.
2. On the Telephony Management screen, type `8` <Enter> to access the Wireless Management menu.

   The Wireless Management menu appears. Refer to Figure 44.

Figure 44 Wireless Management menu

```
1    TOPOLOGY
2    RESOURCES
3    MOBILES

ENTER YOUR CHOICE                ..
```

3. At the Wireless Management menu, type 1 <ENTER>.

   The Wireless Topology menu appears. Refer to Figure 45.

Figure 45 Wireless Topology menu

```
1    NAMES OF CELLS
2    DECT PARAMETERS

ENTER YOUR CHOICE..
```

4. On the Wireless Topology menu, type `1` <ENTER> to access the Names of Cells screen.

Note: Assign all your base stations to one cell name.

5. Use the <TAB> key to move down the line to the cell names.
6. Enter a name for the cell you want to add.
7. Type <CTRL j> to return to the Wireless Topology menu.

Managing Logical Trunks

Use the Wireless Management Resources menus to:

- name logical trunk groups
- define how the trunk groups will operate

Follow these steps to access the screen where you can change the logical trunks settings:

1 At the Wireless Management menu, type `2` <ENTER> to access the Wireless Resources menu. Refer to Figure 46.

Figure 46 Wireless Resources menu

```
1    TRUNK GROUP NAMES
2    TRUNK GROUP DEFINITION
3    BASE STATION ALLOCATION
4    BASE STATION DISPLAY LIST
5    COVERAGE DISPLAY

ENTER YOUR CHOICE                ..
```

2 On the Wireless Resources screen, type `1` <ENTER>.

The Trunk Group Names screen appears.

3 Enter names for each logical trunk group.

Note: You must associate the cells with a logical trunk group name and relate this to a base station name. This procedure sets the communication path for the mobile handset within the DECT module.

Define a trunk group for each base station. Use the tab key to move through the menu.

---

4 Press <CTRL j> to return to the Wireless Resources menu.

5 On the Wireless Resources menu, type `2` <ENTER>.

6 Enter a trunk group name. Enter a name or press the space bar to scroll through the list to pick a name.

7 Press <RETURN>.

8 Enter the cell name, or use the space bar to scroll through the list to pick a name.

LOCATED IN CELL.....

9 Press <RETURN>.

10 Press <CTRL u> to return to the main menu.

Chapter 8
Programming DECT handset records

This chapter describes how to use the Maintenance Console to access the DECT interface to setup the base station record and to confirm the handset (mobile) numbers.

This chapter also describes how to add DNs for handsets to the DECT record. You must use this process if you add DNs after you run the DECT Configuration Wizard.

Confirming the DECT settings

Verify in the DECT module interface that the handsets are set up correctly.

If you do not know how to access the DECT interface, refer to "Opening the Maintenance Console" on page 72.

1 From the main DECT interface menu, type `1` <ENTER>.

The Telephony Management menu appears. Refer to Figure 47.

Figure 47 Telephony Management menu

```
1    EXTENSION DATA
2    EXTERNAL TRUNK DATA
3    NUMBERING PLAN
4    OPERATOR MANAGEMENT
5    CALL DISTRIBUTION MANAGEMENT
6    CALENDAR MANAGEMENT
7    PARAMETER MANAGEMENT
8    WIRELESS MANAGEMENT

ENTER YOUR CHOICE                ..
```

2 Type `8` <ENTER>.

The Wireless Management menu appears. Figure 48 displays the start menu for the processes that follow.

Figure 48 Wireless Management menu

```
1    TOPOLOGY
2    RESOURCES
3    MOBILES

ENTER YOUR CHOICE                ..
```

Identifying base stations

Each base station has a record that defines how it operates. These records are assigned numbers called equipment numbers, which correspond with each port on the two DECT module boards that support the base station. These record numbers also correspond with each port on the DECT module. Refer to "Card Management" on page 75. Therefore, the base station plugged into a specific port on the DECT module uses the information in the corresponding base station record.

To assign change base station records, follow these steps:

1 On the Wireless Management menu, type **2** <ENTER>.

The Wireless Resources menu appears. Refer to Figure 49.

Figure 49 Wireless Resources menu

```
1    TRUNK GROUP NAMES
2    TRUNK GROUP DEFINITION
3    BASE STATION ALLOCATION
4    BASE STATION DISPLAY LIST
5    COVERAGE DISPLAY

ENTER YOUR CHOICE                ..
```

2 Type **3** <ENTER>.

The Radio Base Select menu appears. Refer to Figure 50.

Figure 50 Wireless Resources menu

```
BY EQUIPMENT NUMBER              ..
OR BY ITS TRUNK GROUP            .............
OR BY ITS CELL                   ...............
```

3 Press <ENTER>.

Note: You can also enter an equipment number if you only need to access only one, specific card. (60, 61, 62, 63, 70, 71, 72, or 73)

The screen called Define Radio Base Station 6.0 DECT Access appears. Refer to Figure 51.

Figure 51 Base station screen

RAD. BASE DEFIN. (station/equipment number	DECT
STATUS	IN SERVICE
RAD. BASE TYPE	4 CHAN.
BELONGS TO TRUNK GROUP	[Trunk Group Name]
MOBILE RECORDING ALLOWED	NO
FRAME TS 0->11 AFFECTATION	111111111111
TS NO MODIFICATION ..	
0->9 FREQUENCY ALLOCATION	111111111111
- FREQUENCY NO MODIF	
ANTENNA SELECTION	AUTOMATIC
SYNCHRONIZATION	VIA BIT M FRAME S
DISTANCE FROM MASTER BS	D<100 METERS
TYPE OF BUS	SHORT

4 When you first install the base stations, this record shows the Status to be Disabled.

a Ensure that the Status is **Disabled**.

b Go down to Mobile Recording Allowed and set it to **YES**.

Warning: Set *Mobile Recording Allowed* to YES only for the period when you will be subscribing new handsets. At all other times, ensure this entry is set to No to prevent illegal entry of unauthorized handsets. You must disable the base station before you turn this setting on or off.

c Ensure that the screen displays the following parameters:

- A **Trunk Group** has been specified
- Rad. Base type is set to **4 CHAN**
- Synchronization is set to **VIA BIT M FRAME S**

d Go back to Status and put the base station back in service.

The LED on the base station goes solid while it checks with the DECT module for any updates. After the LED starts blinking, the base station is back in service. To check, press <CTRL j>, then return to the base station record.

5 Press <ESC n> to go to the next record.

6 Ensure that the screen displays the following parameters:

- A **Trunk Group** has been specified
- Rad. Base type is set to **4 CHAN**
- Synchronization is set to **VIA BIT M FRAME S**
- Mobile Recording Allowed is set to **NO**.

7 Go to the Status line and press the space bar to put the base station record in service.

The LED on the base station goes solid while it checks with the DECT module for any updates. After the LED starts blinking, the base station is back in service. To check, press <CTRL j>, then return to the base station record.

8 Repeat steps 5 to 7 for the rest of the base stations.

9 Press <CTRL j> until the Wireless Management menu appears.

Mobile Management

The DECT module interface handset numbers must match the DNs found under the Unified Manager navigation tree Services, Telephony Services, System DNs, All ISDN/DECT DNs. To check this, or to change the DNs on the DECT interface, access the module through the Unified Manager using the **Launch Maintenance Console** command.

Note: Default DECT module DNs:

New Business Communications Manager: 597-624

Upgraded 2.0 Business Communications Manager: 501-532

These defaults assume a system with a three-digit DN structure, and a Start DN of 221. If your system is different, use these numbers as guidelines to find the defaults to your system.

DECT modules can only use DNs from three to six digits long.

Warning: Resetting system DN lengths

If you changed the DN length for your system after a DECT module has been installed, you will no longer be able to record mobiles to the DECT module. You need to reset the DECT module: Resources/DECT/Tools menu/Reset Selected MBM. Then go into the module interface and confirm that the DECT-based DNs still match those on the Unified Manager.

If you do not know how to access the DECT interface, refer to “Opening the Maintenance Console” on page 72.

Follow these steps to find the Mobile menu.

1 On the Wireless Management menu, type 3 <ENTER> (Mobiles).

The Wireless Mobiles menu appears. Refer to Figure 52.

Figure 52 Wireless Mobiles menu

```
1        CREATE MOBILE
2        DELETE MOBILES
3        DISPLAY MOBILES

ENTER YOUR CHOICE              ..
```

2 Use these menus to enter, delete and display a list of the cordless handsets you want to apply to this system.

Listing mobiles (handsets)

The DECT module comes with a default set of mobile extension numbers (DNs). Ensure that these numbers agree with the numbers that are assigned through the Unified Manager **System DNs** DN records.

Use these steps to access the list of existing DNs.

1 On the Wireless Mobiles menu, type 3 <ENTER>.

The Display Mobiles screen appears. Refer to Figure 53.

Figure 53 Display Mobiles screen

```
DN              TYPE   REC.    MODEL          PID
597             DECT   no      ..............
598             DECT   no      ..............
599             DECT   no      ..............
600             DECT   no      ..............
...
624             DECT   no      ..............
```

2 Note which extension numbers are listed.

3 Press <CTRL j> to return to the Wireless Mobile menu.

Identifying handsets

When you need to identify a mobile, or change the extension number (DN), follow these steps:

1 Go to the Base station record and ensure that `Mobile Recording Allowed` is set to **`YES`**.

Refer to "Identifying base stations" on page 88.

Warning: `Mobile Recording Allowed` must only be set to `YES` while you subscribe new handsets. You can also use the DECT Mobile Recording wizard to perform this operation. Refer to "DECT Mobile Recording (Handset Subscription) Wizard" on page 60.

2 On the Wireless Mobile menu, type **`1`** <ENTER>.

The Create Mobile record appears. Refer to Figure 54.

Figure 54 Create mobile record

```
DIRECTORY NUMBER                    (handset DN)
WIRELESS TYPE                       DECT
REFERENCE CELL                      (cell name)
DIRECTORY OF EMERGENCY EXTENSIONS.....
```

3 Enter or change a handset DN.

4 Press <CTRL j> to save the change.

5 Repeat steps 2 and 3 for all the handset DNs you need to enter.

6 Return to the base station record and ensure that:

- Status box reads: **`In service`**
- Mobile Recording Allowed is set to **`No`**

Warning: This entry must be set to `NO` to prevent illegal entry of unauthorized handsets.

7 Exit from the **Launch Maintenance Console** session.

Removing handsets

When you want to block a mobile from the system, or if you changed your DN strategy, delete the mobile extension number.

1 On the Wireless Mobile menu, type **`2`** <ENTER>.

2 At the prompt, type in the DN that you want to remove, or the first and last DNs for a range of DNs.

3 Change CONFIRMATION to YES, and then press <ENTER>.

4 Press <CTRL j> to return to the Wireless Mobile menu, or <CTRL u> to return to the main menu.

Confirming the handset extension record

The mobiles must have a route from the DECT to the Business Communications Manager system. This should be a default to your system, but ensure that the settings described in this section are correct.

To do this procedure, you need to know the DNs for the sets you install.

1 Navigate to the Telephony Management menu. Refer to Figure 47 on page 87.

2 Type `1` <ENTER>. The Extension Data menu appears. Refer to Figure 55.

Figure 55 Extension Data menu

```
1  EXTENSION CHARACTERISTICS
2  LOGICAL SUBSCRIBER MANAGEMENT
3  AUTOMATIC DIRECTORY NUMBER ASSIGNMENT
4  HUNT GROUP CHARACTERISTICS
5  ADD/DELETE EXTENSIONS
6  EXTENSION DIRECTORY
7  CATEGORY MANAGEMENT
8  PROGRAMMING EXTENSIONS
9  OTHER EXTENSION DATA
ENTER YOUR CHOICE                    ..
```

3 Type `1` <ENTER>. The Extension Characteristics menu appears. Refer to Figure 56.

Figure 56 Extension Characteristics menu

```
BY EQUIPMENT NUMBER                  .....

BY DIRECTORY NUMBER                  .....

RECORD DELETED IF DIRECTORY CHANGED  NO
```

4 Tab down to the **`By Directory Number`** field.

5 Enter the DN for the cordless handset, and press <ENTER>.

The Directory Number Selection record appears. Refer to Figure 57.

Figure 57 Handset record, page 1

```
DECT MOBILE                          EXTENSION
SUBSCR. STATUS                       IN SERVICE
DIRECTORY NUMBER                     16289

DID DN PLAN 1                        16289
EXTENSION NAME                       <USER NAME>
REFERENCE CELL
INTEGRATED VOICE BOX (IVB)           NO
SERVICE BEARER                       SPEECH
DIRECTORY OF EMERGENCY EXTENSIONS    ....
DAY CATEGORY                         INTERNATIO.
NIGHT CATEGORY                       INTERNATIO
DAY DISCRIMINATION RANGE             .......
NIGHT DISCRIMINATION RANGE           .......
```

6 Ensure the `DID DN plan 1` field has the same directory number as the previous field. This is the DN number of the handset.

Note: This step makes it unnecessary to assign the DNs to the Loop records in the Business Communications Manager.

7 Use <ESC m> to navigate to the second page. Refer to Figure 58.

Figure 58 Handset record, page 2

```
HOT LINE TYPE                        .....
INTERCOM TYPE                        NO MONITORING

PAGING GROUP NUMBER 1                0..
PAGING GROUP NUMBER 2                0..
ACCESS TO ROUTE TONSTAR              YES
ACCESS TO PAGING                     NC
PRIVILEGED SET                       NC
PICK UP PROTECTION OVERRIDE          NC
LOCKING ALLOWED                      YES
UNLOCKING ALLOWED                    YES
USER MOBILE RECORDING                YES
PICK UP PROTECTION                   NO
NIGHT CATEGORY OVERRIDE              YES
```

8 Ensure that **Access To Route TONSTAR** is set to `YES`.

9 Use <ESC m> to navigate to the third page. Refer to Figure 59.

Figure 59 Handset record, page 3

CALL FORWARDING PROTECTION	NO
DYNAMIC PROTECTION	YES
DO NOT DISTURB ALLOWED	YES
INTRUSION ALLOWED	YES
INTRUSION ACCEPTED	YES
PRE-EMPTIVE REROUTING TO VOICE MAIL	NO
USE OF DISA FUNCTION	NO
CALL WAITING	ACCEPT AND BEEP
RETURN TO CONSOLE ON SPEC. TIME-OUT	NO
EXTERNAL FORWARDING ALLOWED	YES
ASSISTANT FORWARDING ALLOWED	YES
SPEAKER PAGING	YES
ID SENT TO PUBLIC NETWORK	A.I.D.
ID SENT TO PRIVATE NETWORK	A.I.D.
ID SENT CAN BE MODIF. FOR EACH CALL	NO

10 Ensure the **External forwarding allowed** is set to `YES`.

11 Exit to the Unified Manager.

Chapter 9
Maintaining and upgrading DECT software

This chapter describes the backup and restore portion of the DECT Tools, which are located under the Unified Manager first-page **Maintenance** button or under the BRU menu within the Unified Manager application.

Accessing the BRU screen, Unified Manager menu

Note: You must use Microsoft Internet Explorer 5.0 or higher to use the BRU Utility.

1 Start the Unified Manager.

2 Do the following to check that the correct DECT module is selected:

   a On the navigation tree, click the **Resources** key.

   b Click on **DECT**.

   c On the Maintenance Selection tab, confirm the module name, or select the correct module.

3 At the top of the navigation tree, click on **BCM**.

4 Under **Tools**, click on **BRU**.

5 At the prompt, enter the user name and password for the supervisor account.

Note: The supervisor account user name and password are the user name and password you used to access the Unified Manager.

A new window appears.

6 Refer to each section for specific instructions about what to do next.

Accessing the BRU screen, DECT Tools menu

Note: You must use Microsoft Internet Explorer 5.0 or higher to use the BRU Utility.

1 Start the Unified Manager.

2 On the Unified Manager first page, click on the **Maintenance button**.



3 On the left menu of the maintenance site, click on **Maintenance tools**.

4 On the right frame of the Maintenance Tools page, click on the link under the **DECT Tools** heading. The DECT tools page appears.

Figure 60 Maintenance/Maintenance Tools/DECT Tools

DECT Tool	Description/Use of Tool
Time Synchronisation	DECT runs on a seperate processor than the BCM, therefore it is important that you synchronise the time of the DECT processor with the BCM processor. You can schedule this synchronisation to run automatically or you can do it on yourself whenever you want. It is recommended that you do set a regular schedule of once a day.
Firmware Upload	Uploads the latest firmware to your DECT MBM.
Backup	Allows you to backup your DECT MBM programming settings via the Backup and Restore Utility (BRU). In the BRU choose the *Backup* tab, select the BCM component *DECT OAM*, and click *START BACKUP*
Restore	Allows you to restore your DECT MBM programming settings via the Backup and Restore Utility (BRU) . In the BRU choose the *Restore* tab, select the BCM component *DECT OAM*, and click *START BACKUP*
Restore Default Configuration	Restores the Default Configuration of the DECT MBM programming settings.
Companding Laws (ALaw/muLaw)	Changes the Companding (Compress/Expand) Scheme from ALaw to muLaw (or vice versa). ALaw is in use by default. After this process has completed you will then need to run a *firmware upload* before your new settings will take effect.

5 Click on the appropriate link for the action you want to perform (**Backup** or **Restore**)

6 Refer to each section for specific instructions about what to do next.

Backup and Restore DECT module data

One of the special features of the DECT system is that part of the processing for the cordless handsets occurs separately through the DECT module software.

As such, this data must be backed up, particularly prior to updating the software or before any updates on the Business Communications Manager.

This section describes the DECT backup and restore procedures.

Warning: Perform this procedure during slow periods, as it requires system resources.

Backing up DECT data

The following procedure describes the backup process in detail.

1 Open the BRU screen.
Refer to "Accessing the BRU screen, Unified Manager menu" on page 97 or "Accessing the BRU screen, DECT Tools menu" on page 98.

The backup screen appears.

Figure 61 Backup and Restore Utility screen



2 Under Backup Location, ensure the correct path is specified for your backup data. If not, click the **Volume** button, and change the path on the resulting screen.

3 Under **Select BCM Component(s)**, select **DECT OAM**.

4 Under Backup Action, select the schedule information that you want.

- If you select the **Perform the backup now** button, leave the other fields blank and click on the **START BACKUP** button.
- If you select the **Schedule the backup** button, you need to also select the frequency and timing of the backup process. Then click on the **SCHEDULE THE BACKUP** button.

Figure 62 Scheduling a backup, one time



Restoring DECT data

This procedure disrupts service to DECT handsets since it replaces whatever DECT data is currently on the Business Communications Manager.

The following procedure describes how to restore data that you have archived.

1 Open the BRU screen.
Refer to "Accessing the BRU screen, Unified Manager menu" on page 97 or "Accessing the BRU screen, DECT Tools menu" on page 98.

The backup screen appears.

Figure 63 Backup and Restore Utility screen



2 Click on the **Restore** tab to bring up the restore screen.

Figure 64 Backup and Restore Utility, restore screen



3. Under Backup Location, ensure the correct path is specified to your backup data. If not, click the **Volume** button, and change the path on the resulting screen.
4. Under **Select BCM Component(s)**, select **BCM Version Compare**.
5. Under Restore Options, select the radio button to either restore the files only if they are different, or to restore the files, regardless of how they compare to the system version.
6. Click on the **START RESTORE** button.

Chapter 10
Troubleshooting and Alarm Monitoring

This section describes how to monitor alarms on the DECT module and what actions to take when they occur.

Refer to the *Business Communications Manager Installation and Maintenance Guide* and the *Business Communications Manager Programming Operations Guide* for troubleshooting information about the Business Communications Manager.

Radio base station fault on startup

Connect a PHONIS set or an ISDN tester as a replacement for the radio base station. As a rule, this configuration checks the two ISDN pairs for continuity.

Business Communications Manager application control

The Diagnostics section of the Unified Manager contains Service Manager. This utility allows you to monitor the state of the DECT system and Maintenance console. It can also be used to start or stop the service.

1 Open the Diagnostics menu and click **Service Manager**. A list of services appears.

2 Scroll to find the DECT applications. Figure 65 shows the Services List.

Figure 65 Services list



3 Click the **Configuration** menu and click on **Modify Services**.

The Services List for the service you selected appears.

4 In the Status box, click the status you want for the service.

Figure 66 shows the Services List screen.

Table 17 describes the options available.

Figure 66 Services list for DECT Maintenance Console



Table 17 Status options for DECT services

Field	Options	Description
Startup		Determines default behavior for service loading at startup.
	Automatic	Services load automatically at startup.
	Manual	You need to load the services manually.
	Disabled	Feature is disabled.
Status		
	Running	Indicates the service is currently running
	Start	Use this option to start the service on the Business Communications Manager
	Stop	Use this option to close the service on the Business Communications Manager

5 Click the **Save** button to initiate the status change.

Setting up the Maintenance Console

Use the Unified Manager to access the Maintenance Console when you want to administer or perform maintenance to the DECT module. This screen also allows you to start and stop DECT-related services.

Follow these steps to set up the Maintenance Console.

1. Go to **BCM, Resources, DECT**.
2. Click the **Maintenance Selection** tab.
3. Specify the module you want to view.
4. On the menu, open **Tools,** and click on **Launch Maintenance Console**.

   A new window appears with a character-based window.
5. Type <CTRL p>.
6. Type `10` to select VT100 Mode.
7. Perform the required analysis and correction to the menu settings.

Viewing and changing Service Status

This section describes the two screens you can use to view and change the status of the Maintenance Console Server and the Alarm Manager.

1. In the Unified Manager, go to **BCM, Services, DECT**
2. Click either the **Maintenance Console** or the **Alarm Monitor** tab.
3. Change the status, as required.

   Refer to Table 18 for a description of possible status settings

Table 18 Possible status settings

Status	Description
Enable	This value is write-only. For a service that is enabled, one of the operational statuses appears when its Status box is read. When this value is set, the service is brought to the **Up** state.
Disable	This value can be either read or set. When read, this indicates that the component is disabled from operation. When set, it indicates the same, in addition to taking the component to a **Down** state before disabling.

Note: If the maintenance console server is disabled, a maintenance console session is not possible. If the Alarm Monitor service is disabled, DECT alarms are not recorded in the Event Logger. These services must always remain enabled.

Viewing alarms

An enabled status for the Alarms Manager allows the alarms to write to a log on the Business Communications Manager. Access this information through the Unified Manager.

1 Open the Unified Manager.

2 Under **BCM**, highlight **System**.

3 Click the **Fault** menu, then click **Alarm Banner**.

An Alarm Banner appears, listing the number of alarms received under each priority, and the total number of alarms received. Refer to Figure 67.

Figure 67 Alarm Banner



4 Click the button for the fault list you want to view.

The Alarm Browser window appears. This window lists all the alarms in that category.

5 Click the error you want to review.

6 Click **Actions**, and then click on **Display Details**.

The Alarm Details screen appears outlining error details. Refer to Figure 68.

Figure 68 Alarm Details screen



Base station/handset troubleshooting

Table 19 lists some possible problems and an explanation for the situation.

Table 19 Base station/handset troubleshooting

Problem	Description
The base station cannot be loaded. The base station state changes to **Faulty**.	Disable it and try to load the base station as a two-channel base. When software loading succeeds, disable it again and put it in service as a 4-channel base.
When trying to subscribe a handset to the system, it continues to display **Failed**.	Possible causes: • The handset has not been created in the software. • If the handset is subscribed to other bases, delete the bases and try again.
Bad speech quality	Check that the relevant base station is in service. If this is a temporary problem, then it is possible all the channels were busy and the handset was trying to access a more distant base station. If the problem does not correct itself, then cell coverage must be redesigned.
The handset name on the set is not the name that appears on called display sets.	Check the name on the DECT menu, as well as the name entered into the handset itself.
System performance presents problems such as with handovers, noise, one way speech in all areas.	Assuming that the site map and deployment requirements were followed exactly, take everything out of service and return it to service in sequence.

Changing the TCPPort

The TCP port address must only be changed if some future feature requires this port.

To change the TCP port address:

1. In the Unified Manager, go to **BCM, Services, DECT**
2. Click **Maintenance Console**.
3. Enter the new **TCPPort**.
4. Set **Status** to Disable.
5. Wait until the system indicates the port is disabled.
6. Set **Status** back to Enable.

Monitoring the DECT module LEDs

The Power and Status LEDs on the module are both solid green when the module is operating properly. If an LED is off or blinking, use the table below to detect the cause.

Table 20 LED states

Power (working status)	Status (hardware status)	Details
Off	Off	No power applied to the module or failure of the module power converter.
On	Off	Field Programmable Gate Array (FPGA) not downloaded. This indicates that the MSC has not started correctly.
On	Blinking	Operation problem: • no DS256 link detected • DS256 frame alignment lost • Bandwidth not allocated • Module is in maintenance state **Note:** DS256 is the bus that connects the media bay modules to the MSC.
Blinking	Blinking	Hardware problem • partial failure of power converter • thermal overload • fan failure
On	On	Module is ready to operate.

Determining module companding law setting

If you need to replace your DECT module, or if you replaced your Business Communications Manager base unit, you must ensure that the DECT module downloads the correct firmware for the companding law your region requires. The module defaults to a-law.

If you are unsure of which companding law your DECT module is set to, you can access the module interface and check.

1. From the main DECT interface menu, type `1` <ENTER>.

   The Telephony Management menu appears.

2. Type `7` <ENTER>.

   The Parameter Management menu appears.

3. Type `2` <ENTER>.

   The Miscellaneous Parameters menu list.

4. Press <Esc>e on your keyboard to scroll to the end of the list.

5 In Modification of other Parameters, type YES, then press <ENTER>.

6 In Parameter no. in decimal, type 372, then press <ENTER>.

The resulting value will be either blank or 1.

blank = module is set to a-law 1= module is set to µ-law.

Warning: Do not change this setting!

7 If the module needs to be reset to a different companding law, refer to "Configuring the module for µ-law" on page 39 which explains how to perform the various steps that must be taken to download the correct firmware and to reset the module defaults.

Appendix A
Quick reference to DECT module programming

If you have an existing DECT system that you do not want to run the DECT Configuration Wizard on, you can use the Maintenance Console in the Unified Manager to accomplish the configurations you require.

Familiarize yourself with opening the DECT interface. Refer to ”Opening the Maintenance Console” on page 72. Details about setting up system lines and sets are provided in the *Business Communications Manager Programming Operations Guide*.

The chart on the following two pages provides the menu names and a brief description of the information required for each step of programming your DECT module, base stations, and handsets using the Maintenance Console.

DECT Programming Quick Reference Guide

Main DECT interface menu	1 Telephony Management	1 Extension Data 2 External Trunk Data 3 Numbering Plan 8 Wireless Management	(Refer to each section, below)
	3 System Management	2 Card Management 5 Password Management 6 Parameter Management	(Refer to each section below)
System Management	Password Management	Installer Password Password Rec. Mobile	DECT interface access code (optional) handset code, required for handset subscription
System Management	Parameter Management	Parameters screen	Current Language Language #
System Management	Card Management	Cards screen	Cards 6 and 7 only: Line type= ISDN S In service
Telephony Management Wireless management	1 Topology 2 Resources 3 Mobiles	1 Names of Cells 2 DECT Parameters 1 Trunk Group Names 3 Base station allocation 1 Create Mobiles 2 Delete Mobiles 3 List Mobiles	(see each section below)
Wireless Management	1 Topology	2 DECT Parameters	PARI VALUE 0 (module-specific)
Telephony Management	3 Numbering Plans	2 Users Number Plan	4 Access to Directions TONSTAR Norstar directory entries (extensions to be passed to the handset)
			1 Access to extensions Number of Digits (match Business Communications Manager DN length) Range 1 ....., enter handset DN ranges, match Business Communications Manager handset DN range
		3 Incoming Numbering Plan	1 Internal Dialing Default Number of Digits (match Business Communications Manager DN length)
Wireless Management	1 Topology	1 Names of Cells	cell names (alphanumeric, make descriptive of BS locations)
Wireless Management	2 Resources	1 Trunk Group Names	Trunk groups (trunk names) Located in (cell name for trunk)

DECT Programming Quick Reference Guide

		3 Base Station allocation	By equipment number: 6.0 Status: disabled Mobile recording allowed: Yes (for one station only; set all other stations to No) Trunk group: (from list) Rad. Base type: 4 CHAN Synchronization: VIA BIT M FRAME Enable base station. Go to next record
Wireless Management	3 Mobiles	3 List Mobiles	Shows existing listed mobiles and current state
		1 Create Mobiles	Extension Number (handset DN) Wireless type DECT Reference cell (cell name)
		2 Delete Mobiles	Enter DNs you want to remove.
Telephony Management	1 Extension data	1 Extension Characteristics	By Directory Number (DN number of handset or leave blank to view all) Handset record page 1: Directory Number and DID DN PLAN 1 have same number. page 2: Access to Route TONSTAR: Yes page 3: External forwarding allowed: Yes
Business Communications Manager System, Unified Manager settings			
Resources/Media Bay Module/	Bus ##	Ensure module type is Trunk Module	
Services, Telephony services, System DNS	Handset DNs	Set up handsets Default DNs: • New Business Communications Manager: 597-624 • Upgraded 2.0 Business Communications Manager: 501-532	
Services, Telephony services, System DNs	DN of twinned desk set	Enter handset DN in Answer DN	
Unified Manager, various menus		Set up lines, etc., as for other system sets Refer to the *Business Communications Manager Programming Operations Guide*.	
Handset subscription			
Declare Base Number	1		
Enter Code	(eight digits)	Enter the set DN, then add enough digits of the mobile password to make up eight digits.	
Test handsets on system			

Appendix B
Cordless handset verification

If the C4010 or C4020 handset does not subscribe or operate correctly, use the following section to determine if it is properly subscribed and correctly assigned to the DECT system.

Note: If the handset does not follow these procedures, check the user manual that came with the set for specific troubleshooting information.

Determining handset subscription

If the handset is already subscribed to the base station number you want to use, you need to unsubscribe the handset from that number.

This procedure describes how to find out if the handset was previously subscribed.

1. Turn on the handset.
2. Do one of the following:



If this message appears, press ◀ to confirm `OK`, then subscribe the handset.



If this message appears, press ◀, then go to step 3.



3. Press the ◀◀ key until `Select Base` appears.
4. Press the ◀ button, under `Select Base`.
   The system displays the radio base station numbers already in use.
5. If the number you want to use has already been subscribed, refer to "Unsubscribing the handset" on page 116.

Unsubscribing the handset

This section describes how to unsubscribe the handset from a base station number.

Note: If your handset screen is different from that shown below, refer to the user manual that came with your handset for specific details.

1 Press the ◀ button under Menu.

2 Press the ◀▬ key until `Declare` appears.

3 Press the ◀ button under Declare.

This display appears.



4 Scroll to select the base station ▶ ◀.

5 Press the ◀ button, to confirm `OK`.

This display appears.



6 Press the ◀ button, to confirm `Yes`.

This display appears.



7 Press the C button.

The mobile is unsubscribed and the screen returns to the main menu.

8 Subscribe the handset to the DECT system. Refer to "Subscribing DECT cordless handsets" on page 61.

Testing the handset

Test subscribed handsets by walking around the transmission area and confirming that the handset works. This test also confirms that the base stations can transfer the signal, as required.

Use the following procedure to perform more detailed tests, as required.

Warning: This testing must be carried out only by authorized personnel. Entering incorrect commands can cause the handset to malfunction.

There are two ways of testing the handset: while in use and while in the idle mode.

1 Testing the handset while in use:
   - **a** Press the ◀ button to select Menu
   - **b** Press keys 1, 5 and 9 simultaneously.
   - **c** Exit this menu by holding down the C button.

2 Testing an idle handset:
   - **a** Ensure the set is in the idle mode.
   - **b** Press the ◀ button to select Menu.
   - **c** Press 7.
   - **d** Press 6.
   - **e** Press the ▶ and hold it down until the test mode display appears.
   - **f** Exit this menu by holding down the C button.

The handset test screen shown in Figure 69 displays various icons.
Refer to Table 21 on page 118 for the definition of each icon.

Figure 69 Test mode display screen



Table 21 Test mode icon definitions

Icon	Description
▶ ◀	Indicate that PP is in connected mode A + indicates that more than two candidate fixed parts exist. Use the arrow keys to display the other fixed parts.
	This symbol appears if access rights requests are supported by the base station. Bit A44 of high layer capabilities is set.
	This symbol appears if the base station is busy, that is, when the RFP status is set or Blind Slot Information indicates that all the DECT slots are in use.
	MEM, MESS99 and MENU appear on the display to show periodic scanning of the DECT channels by the cordless handset. The number displayed is a state value of the MAC layer.
	This symbol appears during a call if external handover is supported; that is, if bit A45 of higher layer capabilities is set and the Ext h/o indicator has been received from the base station.
XX	RPN (Radio Part Number)
F	Frequency used
S	Slot number used
QQ	Quality (Maximum value: 40 Hex)
RR	RSSI level
C1C1/R1R1	RPN and RSSI of the best candidate FP for roaming or handover
C2C2/R2R2	RPN and RSSI of the second best candidate FP for roaming or handover
C3C3/R3R3	RPN and RSSI of the third suitable candidate FP for roaming or handover
C4C4/R4R4	RPN and RSSI of the third suitable candidate FP for roaming or handover
C5C5/R5R5	RPN and RSSI of the third suitable candidate FP for roaming or handover
C6C6/R6R6	RPN and RSSI of the third suitable candidate FP for roaming or handover
C6C6/R6R6	RPN and RSSI of the third suitable candidate FP for roaming or handover
C8C8/R8R8	RPN and RSSI of the third suitable candidate FP for roaming or handover

Glossary

Antenna diversity

The base station has two internal antennas, which allows it to choose the strongest signal to send and receive.

Authentication key

This is part of the authentication procedure for the portable. When a call starts, the fixed part transmits a challenge to the portable part. The portable part calculates the proper response and sends it. After every call setup, the fixed and portable parts calculate a new authentication key for the next call.

Business Communications Manager

A PBX-like machine attached to the radio base stations that handles call processing, voice messaging, data routing and telephony.

Cell

For the media bay module, the term cell includes a series of radio base stations representing the basic roaming entity for cordless handsets. The media bay module actually knows the cell hosting this cordless handset but does not know the radio area, which is the radio base station to which this set is attached. A message sent to a cordless handset by the media bay module is sent to all radio base stations under this cell. Consequently, a cell typically represents a homogeneous space. One cell contains a maximum of eight base stations.

DSAA

DECT Standard Authentication Algorithm. Used to create the User Authentication Key.

EIC

Equipment Installation Code. This is a distributor reference, for example, Matra Nortel Communications, managed by ETSI.

4-channel station

Refers to a radio base station that can handle four calls simultaneously.

FPN + FPS

Fixed Part Number and Fixed Part Sub-number. This is a network user reference managed by Matra Nortel Communications.

Erlang

One Erlang is an average traffic load caused by one basic DECT speech connection, using one frequency/timeslot pair, all the time.

Handover

A cordless handset can abandon one radio connection for another, either to the same radio base station or to another one.

Map

A chart prepared after the site survey, showing the positions of the radio base stations, the areas they cover, and the cells into which they are grouped.

Media bay module

This is a modularized box containing the hard connections to various peripheral telephony equipment. Media bay modules are installed in bays on the Business Communications Manager or a Business Communications Manager extension unit.

Mobile

The DECT cordless handset.

Overlapping Base Stations

Each base station has the same radio coverage, for example aisle, floor, but manages different groups of cordless handsets.

PARK

Portable Access Right Key (determines the right for this DECT cordless handset)

Password

A secret PIN code used by the fixed and portable parts to establish the right of the portable to use the system.

Radio area

Radio area refers to the space in which this radio base station radiates. If detected by traffic conditions (number of simultaneous calls in this office), several radio base stations can be installed side by side and define almost the same Radio Area. In this case, these radio base stations are referred to as Overlapping Base Stations. The size of each Radio Area varies according to the topology.

Radio area centre

Location of the radio base station or antenna connecting up this radio area.

Radio base station

A radio base station incorporates two identical omni-directional transceivers. A coverage area for a radio base station is in free space, spherical in shape and centred at the radio base station. A radio base station must belong to a trunk.

Radio range

Distance between the radio area center and its boundary limit. A radio range is environment dependent.

Rand f

Random f number, a sequence of up to 10 digits used to calculate the User Authentication Key.

RJ45

The jack used on the radio base stations and the media bay module.

RNIS-S0 terminals

Réseau Numerique (à) Integration (de) Services (French for ISDN).

Site survey

This is the process of surveying the area where you want to locate the base stations and mapping out the best area to mount the components for best reception.

Traffic level

The number of telephone calls being made in a particular area.

Trunk

A communication line that connects the PBX to the central office. A trunk must be associated with a cell. A DECT trunk and a PBX MC 6500 trunk are two different concepts.

Index

A

access to directions 113
access to extensions 113
acronyms 14
add mobile 114
a-law
  setting module to mu-law 39
answer DN 114
antenna losses 22
antennas
  attaching external connections 57
  base station 56
  bi-directional 57
  BNC connector 57
  cables 22
  diagram 22
  extension cord 23
  external 22
  internal 22
  omni-directional 23
antistatic grounding strap 52
attenuation 53

B

back panel 52
backup 99
backup, see also BRU
base station
  antennas 56
  area covered 21
  back panel 52
  cable length 20
  co-located stations 51
  connect external antennas 57
  connecting 55
  declaring base station 62
  default 62
  definition screen 65, 89
  description
  detailed description 21
  disable 26
  environmental specifications 24
  equipment numbers 65
  erase 116
  extension bracket 51
  firmware check 55
  first station distance 20
  grounding 52
  identifying 88
  install on a wall 52
  installation considerations 51
  interface settings 89
  interference 53
  internal antennas 21
  LED status 56
  Mobile Recording wizard 60
  mounting kit 51
  outdoors 51
  overlapping 24
  power
    supply, base station 25
  range 24
  removing the cover 52
  reset, DECT interface 63
  RJ45 connector 21
  see also radio base stations
  signal processing 24
  simultaneous calls 24
  specifications 23
  switches 21
  telephony management 80
  testing
    system 66
  troubleshooting communication 66
  unsubscribing the handset 116
  wireless management 84
base station allocation 113
base station busy indicator 118
base stations
  quick reference to base stations 111
bi-directional antennas 57
BNC connector 57
BRI, DECT 2
BRIP LED 36
BRIS LED 36
BRU 99, 101
BRU, see also backup, restore, and upgrade
bus, see DS30 channel
Business Communications Manager
  checking the region 29
  install media bay module 31
  restart system 36
  setup requirement for DECT 20
  supported DECTs 18

system shutdown 34
busy tone 70

C

C4010 59
C4020 59
C8
card management 75
CA1, base station switch 21
cables
antennas 22, 57
base station 20
base station cable lengths 55
base station connections 53
measurements for base station 53
minimizing interference 53
reconnecting 36
screened pair 53
transmit/receive 21
call capture 67
call forward 67
call numbering, incoming call 83
call shuttle 67
Call waiting
Wizard patch 47
caller ID, handset display 67
CallPilot voice mail 68
cancel call forward 67
card management 75, 113
card port number 88
cell
logical trunk groups 85
roaming area 70
cell names 84, 113
changing languages 74
channel scanning indicator 118
checking the region 29
climatic conditions 24
coaxial cable, antennas 22
cold start 29
commands, DECT interface 27
companding laws
setting module to mu-law 39
components, base station description
conference calls 67
configuration, accessing the wizards 48
connected mode indicator 118
connectors, RJ45 21
conventions, text 14
core firmware 26
create mobile 113, 114
crosstalk 53
Ctrl J 27
Ctrl U 27

D

data links 26
declare base number, handset 114
declare base station 62, 116
DECT
accessing the wizards 48
base station firmware check 55
base station settings 89
caller ID, handset 67
card management 75
cell names 84
changing the TCP Port 107
checking the region 29
checking the region setting 28
choosing DS30 channels 32
connecting base stations 25
connections to media bay module 25
declare base station 62
define radio base station 65
electromagnetic compatibility 3
equipment number, RJ45 jacks
external antennas 57
first base station 20
handling second call on handset 67
handset roaming 69
handset specifications 25
handset subscription
identify base station 88
install media bay module 31
interface commands 27
interface description 2
interference 53
main interface menu 72
module installation process 31
module LED states 108
number of handsets
outside base stations 51
PARI value 79
password 62
programming overview 26
query voice mail 67

quick reference to programming 111
restart system 36
roaming area 70
set password 73
setting DIP switches 32
setup process overview 20
standards and specifications 2
subscribing the handset 61
switch settings for replacement module 33
system management 72
system shutdown 34
telephony management 80
testing setup 66
third call in 67
transfer and conference calls 67
using lines 67
wireless management 84
DECT Configuration wizard 46
DECT Mobile Recording wizard 60
DECT module
backup, restore and upgrade 99
connecting to base station 55
description 18
restoring backed up data 101
setting module to mu-law 39
DECT parameters 79, 113
DECT wizards 45
default
base station 62
DNs 114
password 26
settings, wizard 46
define radio base station 63, 65
delete mobiles 113, 114
deployment
planning requirements 21
setup process 20
dialed number width 27
DIP switches
new module 32
replacing module 33
direct inward roaming 70
disable base stations 26
disconnect power 34
DND on busy 67
DNs
Configuration wizard 46
DECT 33
handset code 62
incoming number plan 83
setting up voice mail 68
download firmware 55
DS30 channel, determining 32

E

electromagnetic compatibility 3
emulation screen 72
enable call waiting
Wizard patch 47
enter code, handset 114
environment
base station specifications 24
standards and specifications 2
equipment number 113
equipment numbers
module jacks 65
see RJ45 connectors
erase subscription 116
ETSI specifications 2
exchange protocol 70
expansion cabinet, disconnect power 34
extension bracket 51
extension characteristics 114
extension cord
antennas 23
generated losses 23
maximum length 23
external antennas
acceptable models 22
base station 21
connecting to base station 57
outdoor base station 51
external handover indicator 118
external trunk data 113
external trunks 80

F

faceplate, see front bezel
fast blink, LED 56
field programmable gate array (FPGA) 108
firmware
at startup 55
call waiting wizard patch 47
requires E1 26
FP roaming/handover indicator 118
frequency band 23

frequency of use indicator 118
front bezel 34

G

gain, antennas 23
generated losses, antenna extension cord 23
go to main menu 27
green LED 36, 56
grounding, inside the base station 52

H

handset
  C4010 and C4020 59
  caller ID 67
  component description 18
  Configuration wizard 46
  declare base number 114
  detailed description 25
  determining current subscriptions 115
  display buttons 61
  erase subscriptions 116
  handling second call 67
  idle 69
  idle mode testing 117
  message waiting indicator
  password 113
  query voice mail 67
  quick reference to programming 111
  registration
  registration key 73
  roaming 69
  set password 73
  set to recording mode 26
  setup test 66
  standards and specifications 2
  subscribing 20, 61
  subscription code 62
  subscription process map 59
  system features 18, 67
  telephony management 80
  test 20, 117
  test screen 117
  third call 67
  unsubscribing 116
  wireless management 84
handsets
  call waiting Wizard patch 47
hardware
  base station considerations 51
  LEDs indicate problem 108

I

idle mode 117
impedance tests 55
incoming numbering plan 83, 113
independent set 67
installer password 73, 113
interface
  base station screen 89
  card management 75
  cell names 84
  commands 27
  define radio base station 65
  identify base station 88
  main menu 72
  numbering plan 80
  PARI value 79
  system management 72
  telephony management 80
  wireless management 84
interference, base station 53
internal antennas
  base station 21
  removing plate 57
internal dialing 113
IP, changing the TCP Port 107
ISDN
  companding laws 39

L

LAL value 70
language management 74
launch maintenance console 72
leak-tight cabinets 51
LED
  base station 56
  media bay modules 108
  monitor 36
  power 108
  states 108
  testing setup 66
list mobiles 113
located in cell 85
located status 69
loop resistance 53
losses at frequency 23

M

MA821X12 75
mailbox 68
make calls 67
maximum length, antenna extension cord 23
media bay module
  component description 18
  connecting base stations 25
  installing 31
Meridian voice mail 68
message waiting 67
message waiting indicator 68
mobile password 113
mobile recording allowed 65, 89
mobile sets, see handsets
mobiles 113
module
  DIP switch settings 32
  DS30 channels 32
  interface commands 27
  LED states 108
  LEDs 36
  numbering plan 80
  PARI value 79
  quick reference to programming 111
  replacing, switch settings 33
  restart system 36
  system shutdown 34
  testing setup 66
module bay 34
mounting kit 51
move up a level 27
MSC, LED indicates trouble 108
mu-law, setting module 39
MWI, see message waiting indicator

N

name, caller ID 67
names of cells 113
non-located status 69
NOSTAR settings 113
number plan syntax 27
numbering plan 80, 113
  incoming 83
numbering plans 113

O

open emulation tool 72
operating temperature 24
operations, LEDs 108
out of range 115
outgoing calls, roaming 70

P

paint warning 24
parameter management 113
PARI value 25, 79, 113
password
  handset 73
  handset code 62
  quick reference guide 113
  record, mobile 73
  setting 73
  system default 26
PBX, C8 2
power
  base station 21
  disconnect server 34
  LED 36, 108
power supply 25
prime set 70
process
  handset subscription 59
  install DECT module 31
  setting up DECT 20
programming
  automatic 55
  quick reference 111
publications, related 15

Q

quality indicator 118

R

radio base station, see base station
radio base type 89
radio channels 23
radio part number indicator 118
receive calls 67
recording mode 26
region, checking 28

registration key 73
relative humidity 24
remove
  cover 52
  internal antenna plate 57
  mobile 114
requirements, deployment 21
reset base station 63
reset, warm reset 24
resources 113
restart system 36
restore 101
restore data 99
RFPI 70
rights requests support indicator 118
RJ45 connector 21, 53, 55, 65
roaming
  direct inward 70
  outgoing calls 70
  overview 69
  restrictions 69
roaming area 70
RPN indicator 118
RSSI level indicator 118

S

S202, base station switch 21
SARI 70
scanning channels indicator 118
screen pair cables 53
second call 67
see also cordless handset
setup process 20
shutdown system 34
signal processing 24
signalling channel throughout 23
simultaneous calls 24
site map 20
site survey
  deployment guide 21
  handsets 25
slot number indicator 118
slow blink, LED 56
specifications
  handset 25
  radio base station 23
  system standards 2
status
  In service 65, 89
  LED 36, 108
storage temperature 24
subscribe handsets 20
subscribing
  determining current connections 115
  erase 116
  Mobile Recording wizard 60
  unsubscribing 116
switches
  CA1 and S202 21
  DIP switch settings 32
symbols 13
synchronization 89
system features, handset 18, 67
system management 72, 113
system restore 36
system shutdown 34
system startup, accessing the wizards 48
systems information 26

T

TCP Port, changing 107
telephony management 80, 113
temperature tolerance range 24
test screen 117
testing
  handsets 117
  idle mode 117
  system 66
text conventions 14
third call in 67
throughput channel 23
topology 113
transfer calls 67
transmission power 23
troubleshooting base station communication 66
trunk group 89, 113
trunk group names 85, 113
twinning handset with fixed set 67
twinning sets 114

U

use frequency indicator 118
users number plan 113

V

voice mail 68
voice mail, query system 67
VT100 emulation 72

W

wall, installing base station 52
wireless management 84, 113
Wizard
  enable call waiting patch 47
wizards
  accessing 48
  Configuration wizard 46
  DECT 45